

Artisan™ 800 Series

Basics Guide

Copyright Notice

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written permission of Seiko Epson Corporation. The information contained herein is designed only for use with this Epson product. Epson is not responsible for any use of this information as applied to other equipment.

Neither Seiko Epson Corporation nor its affiliates shall be liable to the purchaser of this product or third parties for damages, losses, costs, or expenses incurred by purchaser or third parties as a result of: accident, misuse, or abuse of this product or unauthorized modifications, repairs, or alterations to this product, or (excluding the U.S.) failure to strictly comply with Seiko Epson Corporation's operating and maintenance instructions.

Seiko Epson Corporation shall not be liable for any damages or problems arising from the use of any options or any consumable products other than those designated as Original Epson Products or Epson Approved Products by Seiko Epson Corporation.

Responsible Use of Copyrighted Materials

Epson encourages each user to be responsible and respectful of the copyright laws when using any Epson product. While some countries' laws permit limited copying or reuse of copyrighted material in certain circumstances, those circumstances may not be as broad as some people assume. Contact your legal advisor for any questions regarding copyright law.

Trademarks

Epson is a registered trademark, Epson Exceed Your Vision is a registered logomark, and Supplies Central is a service mark of Seiko Epson Corporation.

Artisan is a trademark and Epson Connection is a service mark of Epson America, Inc.

General Notice: Other product names used herein are for identification purposes only and may be trademarks of their respective owners. Epson disclaims any and all rights in those marks.

This information is subject to change without notice.

© 2008 Epson America, Inc. 6/08



Contents

Using the Control Panel	5
Using the Touch Panel	5
Loading Paper	7
Using Special Papers	10
Placing Originals for Copying, Scanning, or Faxing	12
Using the Scanner Glass	12
Using the Automatic Document Feeder	13
Copying a Document or Photo	14
Copying a Document	14
Restoring, Cropping, or Copying Photos	15
Faxing a Document or Photo	18
Connecting to a Phone Line	18
Setting Up Fax Features	19
Sending a Fax	23
Receiving Faxes	25
Printing From Your Camera's Memory Card	26
Inserting Your Camera's Memory Card	26
Inserting a USB Drive	28
Selecting and Printing Photos	29
Printing Layout Sheets	31
Printing From a Camera	33

Printing Special Projects 35

Printing Coloring Book Pages 35

Printing Lined Paper and Graph Paper 37

Printing Personalized Note Paper 37

Printing CDs and DVDs 39

Printing From Your Computer 43

Printing in Windows 43

Printing With a Macintosh 45

Selecting the Correct Paper Type 49

Two-sided Printing 50

Scanning a Document or Photo 52

Basic Scanning 52

Scanning Multiple Pages 54

Maintaining Your All-in-One 55

Checking the Print Head Nozzles 55

Cleaning the Print Head 56

Checking the Ink Cartridge Status 57

Purchasing Epson Ink Cartridges 58

Replacing Ink Cartridges 59

Solving Problems 61

Checking for Software Updates 61


Problems and Solutions 62

Where To Get Help 65


Notices 66


Index 74

Using the Control Panel

The control panel is adjustable. To raise it, lift it as shown below. To lower it, press the  Unlock button.


Caution:

To avoid damaging the Artisan 800 Series, make sure you press the  Unlock button to lower the control panel. Don't try to push it down.



Using the Touch Panel

The touch panel makes it easy to use all the creative features of your Artisan 800 Series.



Caution:





Press the touch panel gently with the tip of your finger; don't press too hard or use sharp objects.

The touch panel displays only the buttons that are available for the project you are working on.

- Whenever you see the ◀ and ▶ buttons, you can press them to view more photos or access more options.
- Whenever you see the ☰ **Menu** button, you can press it to make special settings.
- Whenever you see the **Home** button, you can press it to return to the main menu.
- The touch panel retains the settings from the last time it was used. If you want to start over, simply press **Clear Settings**.
- To save energy, the touch panel goes dark after 13 minutes of inactivity. Touch the screen to wake it up.
- The blue status light at the bottom of the panel flashes when the Artisan 800 Series is printing or performing routine maintenance.

Note:
If the blue status light flashes rapidly, check the Artisan 800 Series for error messages.

You may see the following icons on the screen:


Icon	Meaning
	The Artisan 800 Series is connected to a wired network
	The Artisan 800 Series is connected to a wireless network
ADF	A document is loaded in the automatic document feeder
	The current photo is cropped
	The Fix Red-Eye setting is on for the current photo or all photos

Loading Paper


Your Artisan 800 Series has two paper trays. The main tray is for letter-size, legal-size, A4, or 8 × 10-inch paper. You can load up to 120 sheets of letter-size or A4 plain paper in the main tray. When extended, the tray can hold up to 50 legal-size sheets.

The photo tray is for 4 × 6 or 5 × 7-inch photo paper. You can load up to 20 sheets.

1. Pull out the paper cassette. Then slide back the photo tray and lift it up.




2. Squeeze the edge guides and slide them out. Then insert paper with the glossy or printable side face-down.




Note:

Load letterhead or pre-printed paper face-down, with the top edge at the back of the paper cassette. To load legal-size paper, squeeze the lever and extend the tray.


3. Slide the left edge guide against the paper.




4. Adjust the front edge guide to your paper size.




5. Lower the photo tray.



6. To load paper in the photo tray, squeeze the edge guides and slide them out. Then insert photo paper with the glossy or printable side face-down.




7. Slide the left edge guide against the paper. Then adjust the front edge guide to your paper size.




Note:

Make sure the paper fits under the edge guide.

8. Keep the cassette flat as you insert it.



9. Extend the output tray and flip up the stopper.



For details on paper and instructions on loading envelopes and legal-size sheets, see the on-screen *Epson Information Center*.

Using Special Papers

Epson offers a wide array of high quality papers, making it easy to maximize the impact of your photos, presentations, and creative projects.

You can purchase genuine Epson ink and paper at Epson Supplies CentralSM at www.epson.com/ink3 (U.S. sales) or www.epson.ca (Canadian sales). You can also purchase supplies from an Epson authorized reseller. To find the nearest one, call 800-GO-EPSON (800-463-7766).

Paper name	Size	Part number	Sheet count
Epson Bright White Paper	Letter (8.5 × 11 inches)	S041586	500
Epson Photo Paper Glossy	Borderless 4 × 6 inches	S041809	50
		S042038	100
	Letter (8.5 × 11 inches)	S041141	20
		S041649	50
		S041271	100

Paper name	Size	Part number	Sheet count
Epson Premium Photo Paper Glossy	Borderless 4 × 6 inches	S041808 S041727	40 100
	Borderless 5 × 7 inches	S041464	20
	Borderless 8 × 10 inches	S041465	20
	Letter (8.5 × 11 inches)	S042183 S041667	25 50
Epson Ultra Premium Photo Paper Glossy	Borderless 4 × 6 inches	S042181 S042174	60 100
	Borderless 5 × 7 inches	S041945	20
	Borderless 8 × 10 inches	S041946	20
	Letter (8.5 × 11 inches)	S042182 S042175	25 50
Epson Premium Photo Paper Semi-gloss	Borderless 4 × 6 inches	S041982	40
	Letter (8.5 × 11 inches)	S041331	20
Epson Presentation Paper Matte	Letter (8.5 × 11 inches)	S041062	100
	Legal (8.5 × 14 inches)	S041067	100
Epson Ultra Premium Photo Paper Luster	Letter (8.5 × 11 inches)	S041405	50
Epson Premium Presentation Paper Matte	Borderless 8 × 10 inches	S041467	50
	Letter (8.5 × 11 inches)	S041257 S042180	50 100
Epson Premium Presentation Paper Matte Double-sided	Letter (8.5 × 11 inches)	S041568	50
Epson Ultra Premium Presentation Paper Matte	Letter (8.5 × 11 inches)	S041341	50
Epson Photo Quality Self-adhesive Sheets	A4 (8.3 × 11.7 inches)	S041106	10
Epson Iron-on Cool Peel Transfer Paper	Letter (8.5 × 11 inches)	S041153	10

Placing Originals for Copying, Scanning, or Faxing



Before you copy, scan, or fax, place your documents or photos on the scanner glass (see below) or in the Automatic Document Feeder (see page 13).

Using the Scanner Glass

You can place one or two photos or a document up to letter-size (or A4) on the scanner glass to make color or black and white copies.

1. Open the document cover and place your original face-down on the scanner glass, with the top against the back left corner.

If you're scanning 3×5 - or 4×6 -inch photos, you can place up to two at a time on the scanner glass. Place them at least $\frac{1}{4}$ inch (5 mm) apart.




2. Close the cover gently so you don't move the original(s).


Using the Automatic Document Feeder

You can place up to 30 letter-size (or A4) sheets or 10 legal-size sheets in the Automatic Document Feeder.

1. Open the Automatic Document Feeder paper support, and then move the edge guide outward.



2. Fan the originals, then tap them on a flat surface to even the edges.
3. Insert the originals face-up, top edge first. The **ADF** icon appears on the screen.



4. Slide the edge guide against the originals, but not too tightly.


Copying a Document or Photo

Once you've placed your originals on the scanner or in the Automatic Document Feeder (see pages 12 and 13), you can make color or black-and-white copies. See:

- “Copying a Document” below
- “Restoring, Cropping, or Copying Photos” on page 15

Copying a Document

1. Place your original(s) for copying (see page 12).
2. Load letter-size plain paper, Epson Bright White Paper, or Epson Presentation Paper Matte.
3. Press the **Home** button, if necessary, and select **Copy**. You see this screen.
4. Press **+** or **-** to select the number of copies you want. Or press the number **1** to display the numeric keyboard, then select the number and press **OK**.
5. Select **Color** or **B&W** (black and white) copies.
6. Adjust the density (make the copies lighter or darker) if necessary.
7. To change copy settings, press **≡ Menu** and select **Paper and Copy Settings**. The **Layout** setting should be **With Border** and the **Paper Size** should be **Letter**.
 - To adjust the copy size, select **Reduce/Enlarge**, then choose **Actual** (to print at actual size), **Custom** (to select a percentage), **Auto Fit Page** (to automatically size the image to fit your paper), or one of the specific sizes listed.
 - For the **Paper Type** setting, select **Plain Paper**. (If you loaded a type of paper not listed in step 2, see the table on page 17.)



- For the **Document Type** setting, choose **Text** for plain documents or **Text & Image** if your document contains photos or graphics.
- To change the copy quality, select **Quality**, then choose **Draft**, **Standard Quality**, or **Best**.


For more information about copy settings, see your on-screen *Epson Information Center*.

8. After you finish selecting your settings, press **OK**.
9. Press **Start** to begin copying. To cancel copying, press **Cancel**.


Restoring, Cropping, or Copying Photos

You can copy one or two photos onto 4 × 6-inch, 5 × 7-inch, 8 × 10-inch, or letter-size photo paper for instant photo reprints. You can also restore colors in faded photos, print with or without borders, convert photos to black and white, and crop your photos.

1. Place one or two photos on the scanner glass. Place them at least 1/4 inch (5 mm) apart.
2. Load 4 × 6-inch or 5 × 7-inch paper in the photo tray or 8 × 10-inch or letter-size Epson photo paper in the main tray. Load it printable side face-down.
3. Press the **Home** button, if necessary, and select **Copy**. You see this screen.
4. Press **Menu**, then select **Copy/Restore Photos**.
5. To turn on **Color Restoration** to restore colors in faded photos as you copy, select **On**. (If your photos are not faded, do not turn on **Color Restoration**.)




6. When you see this screen, press **OK** to prescan your photos.
7. When you see a message asking you to select the number of copies, press **OK**.
8. To print more than 1 copy, press **+** or **-** to select the number (up to 99).
9. If you placed two photos on the scanner glass, press **◀** or **▶** to view the second one and select the number of copies.
10. If you want to crop one of your photos and enlarge the resulting image area to fit onto your paper, press **Display/Crop**.
 - To resize the image area, press **+** or **-**.
 - To move the image area, use the arrow buttons.
 - To check the zoomed image, press **OK**.



When you finish cropping your photo, press **OK**.

11. Press **OK** again to continue.
12. To change any of the settings displayed on the screen, press **≡ Menu** and select **Paper and Copy Settings**.
 - To change the paper size, select **Paper Size** and choose the size of paper you loaded. (Paper Size options depend on the Paper Type setting you choose.)



- To change the paper type, select **Paper Type** and choose the setting for the paper you loaded:

For this paper type	Choose this setting
Epson Premium Photo Paper Glossy	Prem. Glossy
Epson Premium Photo Paper Semi-gloss	
Epson Ultra Premium Photo Paper Luster	
Epson Ultra Premium Photo Paper Glossy	Ultra Glossy
Epson Photo Paper Glossy	Glossy
Epson Premium Presentation Paper Matte	Matte*
Epson Ultra Premium Presentation Paper Matte	

* Available only for standard copying (see page 14).

- To change the print layout, select **Borderless**, then choose **On** to expand the image all the way to the edge of the paper (slight cropping may occur) or **Off** to leave a small margin around the image.
- To adjust the amount of image expansion when printing borderless photos, select **Expansion** and choose **Standard**, **Medium**, or **Minimum**, then press **OK** if necessary. (Your printed photos may have white borders if you use the **Minimum** setting.)
- If you want to create a black-and-white copy of a color photo, select **Filter** and choose **B&W**.

13. After you finish selecting your settings, press **OK**.

14. When you're ready to copy, press **Start**. To cancel copying, press **Cancel**.

Note:

When you scan with your computer, you can use additional options to transform faded, dusty, or badly exposed photos into ones with true-to-life color and sharpness. See the on-screen *Epson Information Center* for details.

Faxing a Document or Photo

Your Artisan 800 Series lets you send faxes by entering fax numbers or selecting entries from a speed dial list. Using the Automatic Document Feeder, you can fax up to 30 pages at a time.


See these sections:

- “Connecting to a Phone Line” below
- “Setting Up Fax Features” on page 19
- “Sending a Fax” on page 23
- “Receiving Faxes” on page 25

For more information on faxing and fax settings, see the on-screen *Epson Information Center*.

Connecting to a Phone Line

1. Connect the phone cable from the wall jack to the **LINE** port on the back of the Artisan 800 Series.



Note:

If you're connecting the Artisan 800 Series to a DSL phone line, you must plug a DSL filter into the wall jack or you won't be able to use the fax or telephone equipment as described below. Contact your DSL provider for the necessary filter.

2. To use a telephone or answering machine, you need a second phone cable. Connect one end of the cable to the telephone or answering machine, and connect the other end to the **EXT.** port on the back of the Artisan 800 Series.

When you receive a call, if the other party is a fax and you pick up the phone or the answering machine answers, the Artisan 800 Series automatically begins receiving the transmission. If the other party is a caller, the phone can be used as normal or a message can be left on the answering machine.

Note:

Your phone or answering machine must be connected to the **EXT.** port (not to a wall jack) for the Artisan 800 Series to detect incoming fax calls properly. It's a good idea to set the Artisan 800 Series to pick up calls after your answering machine; to adjust the number of rings after which the Artisan 800 Series answers, press the **Home** button and select **Setup**, select **Fax Setting**, select **Communication**, and select **Rings to Answer**.

Setting Up Fax Features

Before sending or receiving faxes, you may want to create a fax header, select your fax preferences, and set up a speed dial list of frequently used fax numbers.

- “Entering Fax Header Information” on page 20
- “Select Scan and Print Settings” on page 21
- “Setting Up a Speed Dial List” on page 22

Note:

To change other settings or print fax reports, see the on-screen *Epson Information Center*.

Entering Fax Header Information

You should enter fax header information before sending faxes so that recipients can identify their source.

Note:

If you leave the Artisan 800 Series unplugged for a long period of time, the date and time settings may not be retained. See the on-screen *Epson Information Center* for instructions on setting the date and time.

Entering Your Sender Name

1. Press the **Home** button, if necessary, and select **Setup**.
2. Press ◀ or ▶ and select **Fax Setting**.
3. Press ◀ or ▶ and select **Header**.
4. Select **Fax Header**. You see the fax keypad.
5. Use the keypad to enter the header information (see page 21). You can enter up to 40 characters or digits for your name and other contact information.
6. Press **OK** to return to the Header menu.

Fax Header			
1 Symb.	2 ABC	3 DEF	BS
4 GHI	5 JKL	6 MNO	⏮
7 PQRS	8 TUV	9 WXYZ	□_□
*	0	#	

Entering Your Phone Number

1. Select **Your Phone Number** from the Header menu.
2. Use the keypad to enter your phone number, up to 20 digits (see page 21). You don't need to use dashes. Use the # button to type the + symbol for an international number.
3. Press **OK** to return to the Header menu.

Enter Phone Number			
1 Symb.	2 ABC	3 DEF	BS
4 GHI	5 JKL	6 MNO	⏮
7 PQRS	8 TUV	9 WXYZ	□_□
*	0	#	

Using the Keypad to Enter Numbers and Characters

- To enter phone numbers, select them on the keypad.
- To enter text, use the keypad as you would on a cell phone. Look for the button that has the character on it you want to type. Then press the button repeatedly until that character displays on the screen.



- Press **1 Symb.** to enter these characters: ! # % & ' () * + , - . / : ; = ? @ ~
- To move the cursor, add a pause or space, or delete a character:

Button	Function
◀ or ▶	Moves the cursor left or right.
BS	Deletes a character (backspace).
⏸	Inserts a pause symbol (–).
□_□	Inserts a space.

Select Scan and Print Settings

Use these settings to adjust the image quality of incoming and outgoing faxes, select the paper size loaded in your Artisan 800 Series, select the size at which faxes are printed, and select when you want printed reports.

1. Press the **Home** button, if necessary, and select **Setup**.
2. Press **◀** or **▶** and select **Fax Setting**.
3. Select **Scan & Print Setup**.
4. Adjust any of the following settings:


Setting and options	Description
Resolution Standard, Fine, Photo	Sets the scan resolution of outgoing faxes and the print quality of received faxes.
Contrast –4 to +4	Sets the contrast when sending and receiving faxes.
Paper Size Letter (default), Legal, A4	Indicates the size of paper loaded in the Artisan 800 Series.

Setting and options	Description
Auto Reduction Off, On (default)	Sets whether large incoming faxes are reduced to fit on the selected Paper Size (On), or printed at their original size on multiple sheets (Off).
Last Transmission Report Off, On Error (default), On Send	Sets when reports are printed for transmitted faxes. Select Off to turn off report printing, On Error to print reports only when an error occurs, or On Send to print reports for every fax you send.

Setting Up a Speed Dial List

You can create a speed dial list of fax numbers so you can quickly select them for faxing. You can also set up group dial lists to send the same fax message to multiple recipients (see the on-screen *Epson Information Center* for details). The Artisan 800 Series lets you create up to 60 combined speed dial and group dial entries, add names to identify the recipients, and print a list for easy reference (see page 23).


1. Press the **Home** button, if necessary, and select **Setup**.
2. Press **◀** or **▶** and select **Fax Setting**.
3. Select **Speed Dial Setup**.
4. Select **Create**. You see the list of available entries.



Note:

To edit or delete an entry from an existing list, select **Edit** or **Delete** instead.

5. Use the arrows to select any available number for the entry you want to add, then press **OK**.
6. Use the keypad to enter the phone number (see page 21), then press **OK**.
7. Use the keypad to enter a name to identify the speed dial entry (see page 21), then press **OK**. You return to the Speed Dial Setup menu.
8. To add another speed dial entry, select **Create** and repeat the steps above.



Printing Your Speed Dial List

To print your speed dial or group dial list, follow these steps:

1. Press the **Home** button, if necessary, and select **Fax**.
2. Press **Menu**, then press **◀** or **▶** and select **Fax Report**.
3. Select **Speed Dial List**.
4. Make sure letter-size or A4 paper is loaded, then press **Start** to begin printing the list.




Sending a Fax

You can send a fax by manually entering a fax number (as described below), redialing the previous fax number, or selecting an entry from your speed dial list.

1. Place your original(s) for faxing (see page 12).
2. Press the **Home** button, if necessary, and select **Fax**.
3. Press **123**, then use the numeric keypad to enter the fax number (up to 64 digits). Then press **OK**.

Note:

To dial the number using your telephone, by redialing, or by selecting from your speed dial list, see page 24.



4. Select **Color** or **B&W**.

Note:

If the recipient's fax machine prints only in black and white, your fax is automatically sent in black and white even if you select **Color**.

5. Press **OK**, if desired, to see a summary of your fax transmission settings.
6. Press **Start** to begin scanning and faxing your document. (To cancel, press **Cancel**.)


If you are scanning with the Automatic Document Feeder, your document is automatically scanned and faxed.

If you placed your document on the scanner glass, you see this screen after the first page is scanned.

If you need to fax additional pages, place your original on the scanner glass or in the Automatic Document Feeder. Press **Yes**, then press **OK** to continue. If you don't need to fax another page, press **No**.

Note:

If the fax number is busy, you see a redialing message and the Artisan 800 Series redials after one minute. To redial immediately, press **Redial**.



Other Ways to Dial a Fax Number

In addition to manual transmission, here are some other ways you can enter a fax number:

- If you've connected a telephone to the Artisan 800 Series, you can dial the fax number from the phone. When you see the screen at right, select **Send**.

Note:

Don't hang up the phone until the Artisan 800 Series begins transmitting the fax.



- To select a speed dial or group dial entry, press **Speed Dial** or **Group Dial**. Select the name of the speed dial entry you want to use.
- To redial the last fax number you used, press **Redial**. The last fax number is displayed on the screen.

Receiving Faxes

Before receiving faxes, make sure you load plain paper and select the **Paper Size** setting that matches the size of paper you've loaded (see page 21). If the incoming fax pages are larger than the paper size you loaded, the fax size is reduced to fit or printed on multiple pages, depending on the **Auto Reduction** setting you select.

If you run out of paper during printing, you see the error message **Paper out**. Load more paper and press the **Start** button to continue.

To receive faxes automatically, make sure you see a green light next to the **Auto Answer** button on the screen. The light stays on when Auto Answer mode is enabled. To change the answer mode, press the **Auto Answer** button.


Note:

To change the number of rings after which the Artisan 800 Series answers, press the **Home** button, select **Setup**, select **Fax Setting**, select **Communication**, and select **Rings to Answer**.

Manually Receive a Fax

To receive a fax manually, press the **Auto Answer** button to turn off this feature (and the light). Then follow these steps:

1. When your telephone rings, lift the phone off the hook. You see this screen.
2. Select **Receive** and press the **Start** button.
3. After all the pages are received, you see this screen again. Replace the phone on the hook.



Printing From Your Camera's Memory Card

The Artisan 800 Series lets you print photos from your digital camera's memory card, or by connecting your camera directly and using its DPOF™ settings. You can also print photos stored on a USB drive. See these sections:

- “Inserting Your Camera's Memory Card” below
- “Inserting a USB Drive” on page 28
- “Selecting and Printing Photos” on page 29
- “Printing Layout Sheets” on page 31
- “Printing From a Camera” on page 33



Inserting Your Camera's Memory Card

1. Insert the card into the correct slot, as shown. Insert just one card at a time.

Upper slot: SD™, SDHC™
miniSD™*, miniSDHC*
microSD*, microSDHC*
MultiMediaCard™
MMCplus, MMCmobile*, MMCmicro*
Memory Stick™
Memory Stick Duo™*
Memory Stick Micro™*
Memory Stick PRO™
Memory Stick PRO Duo™*
Memory Stick PRO-HG Duo*
MagicGate™ Memory Stick
MagicGate Memory Stick Duo™*
xD-Picture Card™
xD-Picture Card Types H and M

Lower slot: CompactFlash®
Microdrive™

* Adapter required




Make sure the image files on your card meet these requirements:

File format	JPEG with the Exif version 2.21 standard
Image size	80 × 80 pixels to 9200 × 9200 pixels
Number of files	Up to 9990 (If there are more than 999 photos on the card, you can select a group of photos to display.)

- 2. After you insert the card, the memory card access light flashes, then stays on.
- 3. See page 29 to select and print your photos.

Memory card access light






Removing Your Card

After you finish printing your photos, follow these steps to remove the card:

- 1. Make sure the memory card access light is not flashing.

Caution:

Do not remove the card or turn off the Artisan 800 Series while the memory card access light is flashing, or you may lose data on the card.


- 2. If the Artisan 800 Series is connected to your computer, do one of the following:
 - **Windows:** Click the  or  icon on the taskbar and select **Safely remove USB Mass Storage Device**.
 - **Macintosh:** Drag the  removable disk icon from your desktop into the trash.
- 3. Pull the card straight out of its slot.


Inserting a USB Drive

You can print from an external storage device connected to the Artisan 800 Series, such as a USB flash drive or CD burner.

Note:

Epson cannot guarantee the compatibility of any drives. You may not be able to print photos from the storage device if they were saved to the device using a product other than the Artisan 800 Series.

1. Remove any inserted memory card from the Artisan 800 Series.
2. Insert your USB flash drive or the USB cable for your external drive into the  USB connector on the front of your Artisan 800 Series.




3. Insert storage media (such as a CD) into your drive, if necessary.
4. If there are folders on your drive, select the folder you want and press OK.
5. See the next section to select and print your photos.

Note:

Before removing your USB drive, make sure its access light is not flashing. Also see step 2 in "Removing Your Card" on page 27.

Selecting and Printing Photos

1. Load Epson photo paper. See page 10 for a list.
2. Press the **Home** button, if necessary, and select **Photos**.
3. Select **View and Print Photos** and press **OK**.
4. Press **◀** or **▶** to move through your photos and display one you want to print.



Tip:

If **View Auto Correct: Off** appears on the screen, press the **View Auto Correct** button to see how the image will look if **Fix Photo** is turned on (see page 30).

5. To print more than one copy, press **+** or **-** to select the number of copies you want of that photo.
6. To crop the photo, press the **Display/Crop** button and see page 16 for instructions.

Note:

In cropping mode, you can press **≡ Menu** to rotate the image.

7. Press **◀** or **▶** to view other photos, select the number of copies, and crop, if desired.
8. When you're done selecting photos, press **OK**. You see the Print Preview screen.
9. Press **≡ Menu**, select **Print Settings**, and select **Paper Size**. Choose the size of paper you loaded.

Note:

Paper Size options depend on the **Paper Type** setting you choose.



10. Select **Paper Type**, then choose the correct setting for the type of paper you loaded:

For this paper type	Choose this setting
Epson Premium Photo Paper Glossy	Prem. Glossy
Epson Premium Photo Paper Semi-gloss	
Epson Ultra Premium Photo Paper Glossy	Ultra Glossy
Epson Photo Paper Glossy	Glossy
Plain paper	Plain Paper
Epson Bright White Paper	
Epson Presentation Paper Matte	
Epson Premium Presentation Paper Matte	Matte
Epson Ultra Premium Presentation Paper Matte	

11. When you're done selecting settings, press **OK**.
12. If desired, press **Menu** and select **Photo Adjustments** to turn on red-eye reduction or other photo-enhancing features. When you're done selecting settings, press **OK**.

Note:
For the best quality printing, leave **Fix Photo** turned on. This automatically adjusts brightness, contrast, and saturation to best effect.

Fix Photo uses a sophisticated face recognition technology to optimize photos that include faces. For this to work, both eyes and the nose must be visible in the subject's face (without sunglasses). If your photo includes a face with an intentional color cast, such as a bronze statue, you may want to turn off this setting to retain the special color effects.

13. When you're ready to print, press **Start**.


To cancel printing, press **Cancel**.

Note:
To switch the display screen from displaying one photo at a time to 9 photos at a time, press the **Display/Crop** button 3 times when viewing your photos.

Printing Layout Sheets

You can print the same photo or multiple photos on a single sheet of paper using the Artisan 800 Series templates.

1. Press the **Home** button, if necessary, and select **Photos**.
2. Press ◀ or ▶ and select **Photo Layout Sheet**. You see this screen:



3. Press ◀ or ▶ and select one of the layout settings shown on the screen.

Note:


As indicated by the icons, some of the layouts let you place different photos on the same sheet.

4. Select **Paper Size**, then choose the size of paper you loaded.

Note:

Paper Size options depend on the **Paper Type** setting you choose.

5. Select **Paper Type**, then choose the correct setting for the type of paper you loaded (see the table on page 30).
6. When you're done selecting settings, press **OK**. Depending on the layout you selected, you might see this screen:



Select **Automatic layout** to let the Artisan 800 Series place images in the layout sheets for you, or select **Place photos manually** to arrange the images yourself.

7. When you see this screen, press **OK**.




8. Follow the instructions on the screen to add photos to the layout sheet.

Note:

If you don't select enough photos to fill the layout you selected, you will see a warning message, and the layout will have some blank spaces.

9. To print more than 1 copy of the sheet, press **+** or **-** to select the number (up to 99).



10. Press **Menu** to change any of the settings displayed on the screen. Select one of the following options:
 - **Print Settings** to change the paper type and size, or other print settings
 - **Photo Adjustments** to turn on red-eye reduction or other features

When you're done selecting settings, press **OK**.

11. When you're ready to print, press **Start**.

To cancel printing, press **Cancel**.


Printing From a Camera


If you have a digital camera that supports PictBridge™ printing, you can connect it to the Artisan 800 Series and print your photos directly from the camera. Check your camera manual to see if it is compatible.

Your photos must be in JPEG format and sized from 80 × 80 to 9200 × 9200 pixels.


Note:

Epson cannot guarantee the compatibility of any cameras. Some combinations of paper type, size, and layout may not be supported, depending on your camera and the Artisan 800 Series settings.

1. Remove any inserted memory card from the Artisan 800 Series.
2. Connect the USB cable that came with your camera to the  USB connector on the front of your Artisan 800 Series.



3. Turn on your camera. You see a connection message on the Artisan 800 Series display screen.
4. Load Epson photo paper (see page 7).
5. Press the Home button, if necessary, and select **Setup**.
6. Press ◀ or ▶ and select **PictBridge Setup**. You see this screen:




7. Select the following settings (see the on-screen *Epson Information Center* for details):
 - **Print Settings** to select the paper type and size, or other print settings
 - **Photo Adjustments** to turn on red-eye reduction or other features

When you're done selecting settings, press **OK**.

8. Follow the instructions that came with your camera to select and print your photos.

Printing Special Projects

You can use your Artisan 800 Series to make coloring book pages for your kids, ruled paper and graph paper for homework projects, and even note paper personalized with your favorite photos. You can also print custom designs directly on ink jet-printable CDs and DVDs.




See these sections:

- “Printing Coloring Book Pages” below
- “Printing Lined Paper and Graph Paper” on page 37
- “Printing Personalized Note Paper” on page 37
- “Printing CDs and DVDs” on page 39


Printing Coloring Book Pages

Your Artisan 800 Series can turn any photo or drawing into a coloring book page.


1. Load letter- or A4-size plain paper, Epson Presentation Paper Matte, or Epson Premium Presentation Paper Matte.
2. Press the **Home** button, if necessary.
3. Press ◀ or ▶ and select **Coloring Book**. You see this screen:



4. Open the document cover. Place a photo or drawing face-down on the glass, in the back left corner, and press **OK**.
5. Select the type of photo or drawing you are using:



6. Select the paper size and type:




7. When you're ready to print, press **Start**. To cancel printing, press **Cancel**.

Printing Lined Paper and Graph Paper

You can have the Artisan 800 Series print lined paper or graph paper whenever you need it.

1. Load plain letter- or A4-size paper.
2. Press the **Home** button, if necessary.
3. Press ◀ or ▶ and select **Print Ruled Papers**. You see this screen:




4. Press ◀ or ▶ and select **Wide Rule**, **Thin Rule**, or **Grph Paper**. Select an option that matches your paper size.
5. When you see a message asking you to load paper, press **OK**.
6. To print more than 1 sheet, press **+** or **-** to select the number (up to 99).
7. When you're ready to print, press **Start**. To cancel printing, press **Cancel**.

Printing Personalized Note Paper


You can print lined or unlined note paper, personalized with a photo in the background.

1. Load plain letter- or A4-size paper.
2. Insert a memory card (see page 26) or USB drive (see page 28).
3. Press the **Home** button, if necessary.
4. Press ◀ or ▶ and select **Print Ruled Papers**.


5. Press ◀ or ▶ and select one of the **Note Pad** settings (with or without lines) for the size paper you loaded in the printer.



6. When you see this screen, press **OK**.



You see a preview of how your stationery will look with a photo in the background.



7. To rotate the layout, press **Rotate**.
8. Press ◀ or ▶ to move through your photos and display the one you want to use for your stationery.
9. Press **OK**.
10. When you see a message asking you to load paper, press **OK**.

11. To print more than 1 sheet, press **+** or **-** to select the number (up to 99).
12. When you're ready to print, press **Start**. To cancel printing, press **Cancel**.


Printing CDs and DVDs

You can use your Artisan 800 Series to print a design right onto ink jet-printable CDs and DVDs. Follow these steps to transfer one or more photos from a memory card or USB drive onto your CD/DVD.

Note:


You can also copy a CD/DVD design, print a jewel case insert, and create your own designs using the Epson Print CD software that came with your Artisan 800 Series. For more information, see the on-screen *Epson Information Center*.

1. To prevent errors, burn files, music, or video onto your CD/DVD before printing on it.
2. Insert your memory card (see page 26) or USB drive (see page 28).
3. Press the **Home** button, if necessary, and select **Photos**.
4. Press **Left** or **Right** and select **Print on CD/DVD**. You see this screen:




5. Select 1-up, 4-up, or CD/DVD Variety (10-up) to indicate the number of photos in the layout.
6. Select **Automatic layout** or **Place photos manually**, if necessary.
7. Press **Left** or **Right** to move through your photos and display one you want to print. Press the **+** button to select the number of copies you want of that photo. For multiple photo layouts, repeat for each photo you want to include. You can also press **Display/Crop** and crop your photos (see page 16 for instructions).


8. Press OK when you're done selecting photos. You see this screen:




9. If necessary, adjust the inner and outer diameter of your CD as shown on the screen, then press OK.



10. If desired, select **Test Print on Letter/A4 paper** and follow the on-screen instructions to print a test on plain paper.
11. If your test is satisfactory, select **Print on a CD/DVD**. The CD/DVD tray extends automatically and you see this screen:




12. Raise the control panel all the way up.




13. Place your disc on the tray with the label side up. Gently press it in place (it does not snap in).

Caution:


Do not try to pull the CD/DVD tray out; it extends automatically as far as possible.



14. Press the  CD Tray button to position the CD/DVD for printing.

Caution:

Do not turn the Artisan 800 Series off with a CD or DVD loaded in it. Always remove the disc first.

15. Press  Menu to change any of these settings:


- **Print Settings** to change the print density or other print settings
- **Photo Adjustments** to turn on red-eye reduction or other features

When you're done selecting settings, press OK.

16. When you see this screen, press **Start** to begin printing.




17. After your CD/DVD is printed, the tray extends from the Artisan 800 Series. Remove your disc.



18. Press the **CD Tray** button to put away the CD/DVD tray.

19. Press the **Unlock** button to lower the control panel.



Note:

After printing, handle your CD/DVD carefully. You may need to wait up to 24 hours for the ink to dry fully before inserting it in a drive. Keep printed discs away from moisture and direct sunlight.

Printing From Your Computer

This section describes the basic steps for printing a photo or document stored on your Windows® or Macintosh® computer. For instructions on two-sided printing, see page 50. For additional printing instructions, see the on-screen *Epson Information Center*.

Before you start, make sure you've installed your printer software and connected the Artisan 800 Series to your computer as described on the *Start Here* sheet.


Tip:

It's a good idea to check for updates to your Artisan 800 Series software. See page 61 for instructions.

You can also create personalized photo greeting cards, calendars, and more using the ArcSoft® Print Creations™ software included with your Artisan 800 Series. To get started, double-click the Print Creations icon on your desktop.

Printing in Windows

1. Open a photo or document in an application.
2. Open the File menu and select Print. You see a window like this one:



Select EPSON Artisan 800 Series

Click here to open your printer software

3. Select **EPSON Artisan 800 Series**, then click the **Preferences** or **Properties** button.

Note:


If you see a **Setup**, **Printer**, or **Options** button, click it. Then click **Preferences** or **Properties** on the next screen.

4. On the **Main** tab, select the basic print settings. Make sure you choose the correct paper **Type** setting for the paper you are using (see page 49).

Select the type of document you're printing (choose **Photo** or **Best Photo** for photos)

Select your paper **Type**

Select your paper **Size**



Click here for borderless photos

Select your document or photo **Orientation**

Note:

For quick access to the most common settings, click the **Shortcuts** tab and select one of the presets. You can create your own presets by clicking the **Save Settings** button on the **Advanced** tab. For details, see your on-screen *Epson Information Center*.


5. To improve the color, contrast, and sharpness of photos, select **Fix Photo**.
6. To reduce or remove red-eye effects in photos, select **Fix Red-Eye**.
7. If you want to reduce or enlarge your printout, or print double-sided (see page 50), click the **Page Layout** tab and select settings as necessary.
8. For more printing options, click the **Advanced** tab.

Note:

For more information about print settings, click **Help** or see your on-screen *Epson Information Center*.

9. Click **OK** to save your settings.

10. Click **OK** or **Print** to start printing. This window appears and shows the progress of your print job.




Printing With a Macintosh

See the section below for your Mac OS® operating system.

Mac OS X 10.5

1. Open a photo or document in an application.
2. Open the File menu and select **Print**.
3. Select **EPSON Artisan 800** as the Printer setting.



4. Click ▼ to expand the Print window, if necessary.


5. Select the basic page setup options. For borderless photos, choose a **Paper Size** setting with a **Borderless** option.

Note:

If the setting you want isn't shown (for example, **Scale**), check for it in your application before printing. Or check for it in the settings for your application at the bottom of this window. (If you're printing from Preview, you see the settings shown below.)




6. Choose **Print Settings** from the pop-up menu, then select the following print settings:




7. Choose any other printing options you may need from the pop-up menu. See the on-screen *Epson Information Center* for details.

Note:


To reduce or remove red-eye effects in photos, choose **Extension Settings** from the pop-up menu and select **Fix Red-Eye**.

8. Click **Print**.
9. To monitor your print job, click the  icon in the dock. Select your print job, then select an option to cancel, pause, or resume printing, if necessary.



Mac OS X 10.3 and 10.4


1. Open a photo or document in an application.
2. Select **Page Setup** from the File menu. Select the following settings:




For borderless photos, choose a **Borderless** option in the Paper Size list for your paper size.

3. Click **OK** to close the Page Setup window.

4. Select **Print** from the File menu. You see a window like this one:



5. Choose **Print Settings** from the pop-up menu, and select the following print settings, as necessary:



Note:

In certain programs, you may need to select **Advanced** before you can select **Print Settings**. For more information about printer settings, click the ? button.


6. Click the **Advanced** button to change additional settings.

Note:

For more information on advanced settings click ?.

7. Choose any other printing options you may need from the pop-up menu. See the on-screen *Epson Information Center* for details.
8. Click **Print**.

9. To monitor your print job, click the  icon in the dock (or click the  Print Center icon and double-click **Artisan 800** on the next screen).



Selecting the Correct Paper Type

Select the correct **Type** (see page 44) or **Media Type** (see page 46 or 48) setting in your printer software. This tells the Artisan 800 Series what kind of paper you're using, so the ink coverage can be adjusted accordingly.

For this paper/media	Select this setting
Plain paper Epson Bright White Paper	Plain Paper/Bright White Paper
Epson Ultra Premium Photo Paper Glossy	Ultra Premium Photo Paper Glossy
Epson Premium Photo Paper Glossy	Premium Photo Paper Glossy
Epson Photo Paper Glossy	Photo Paper Glossy
Epson Presentation Paper Matte	Presentation Paper Matte
Epson Premium Photo Paper Semi-gloss	Premium Photo Paper Semi-gloss
Epson Ultra Premium Photo Paper Luster	Ultra Premium Photo Paper Luster
Epson Premium Presentation Paper Matte Epson Premium Presentation Paper Matte Double-sided Epson Ultra Premium Presentation Paper Matte Epson Photo Quality Self-adhesive Sheets Epson Iron-on Cool Peel Transfer Paper	Premium Presentation Paper Matte
Envelopes	Envelope

Two-sided Printing

If you have the optional auto duplexer, you can print on both sides of the page automatically. To purchase the auto duplexer from Epson, see page 65.

With Windows, you can configure the printer software and perform two-sided printing even if you don't have the auto duplexer.


Note:

For detailed instructions on two-sided printing and installing or removing the auto duplexer, see the on-screen *Epson Information Center*.

Windows

Follow the Windows printing instructions beginning on page 43, but complete the additional steps below before you start printing.

1. Click the **Page Layout** tab in the printer software.



2. Select **Auto** as your 2-sided printing setting if you've installed the auto duplexer, or **Manual** if you don't have the auto duplexer.

Note:


When you use the **Manual** setting, the printer software will prompt you to reload the printed pages as necessary.

3. If you're printing on plain paper and you notice that ink smears or bleeds through the page, click **Adjust Print Density** to reduce the print density and increase the ink drying time.

Mac OS X

Follow the Macintosh printing instructions beginning on page 45 (Mac OS X 10.5) or page 47 (Mac OS X 10.3 and 10.4), but complete the additional steps below before you start printing.

1. Select **Auto Duplex Printing Settings** from the pop-up menu.



2. Select **Auto Duplex Printing**.

Note:

If you see a message indicating that the auto duplexer is not installed, open **EPSON Printer Utility3** (in the Applications folder on your hard drive), select **Artisan 800 Series**, click **OK**, click the **Printer and Option Information** button, and click **OK** again. Then close and reopen the print window.

3. If you're printing on plain paper and you notice that ink smears or bleeds through the page, you may need to reduce the print density and increase the ink drying time.

Scanning a Document or Photo

You can use your Artisan 800 Series to scan original documents and photos and save them as digital files on your computer.

You can also turn scanned documents into editable/searchable text using ABBYY® FineReader® Sprint Plus (OCR software) included with your Artisan 800 Series. For more information, see the on-screen *Epson Information Center*.

The Epson Scan software provides three scanning modes:

- **Office Mode** previews your image and scans text documents quickly.
- **Home Mode** previews your image and provides preset options for scanning.
- **Professional Mode** previews your image and provides a full array of tools.

Note:


For detailed scanning instructions, see the on-screen *Epson Information Center*.

Basic Scanning

You can scan from any TWAIN-compliant application using Epson Scan. Or you can start Epson Scan directly from your computer and save your image to a file.

1. Open the document cover and place your original face-down on the scanner glass, in the back left corner, as shown on page 12.
2. Close the cover gently so you don't move the original.
3. Do one of the following to start Epson Scan:
 - **Windows:**
Double-click the **EPSON Scan** icon on your desktop.
 - **Macintosh:**
Double-click **EPSON Scan** in the Applications folder.
 - If you are scanning from an application, start your application. Then open the File menu, choose **Import** or **Acquire**, and select your Artisan 800 Series (if necessary).

4. Epson Scan opens in Office Mode the first time you use it. (You can change the scan mode using the Mode selector in the upper right corner.)



Note:

You cannot use Home mode to scan with the Automatic Document Feeder.

5. Click **Scan** and select the name, location, and format (such as PDF) for your scanned document.
6. Click **OK**. The image is scanned and you see its icon in Windows Explorer or Macintosh Finder.

Scanning Multiple Pages

You can scan a multiple-page document and save it on your computer in PDF or another format. With the Automatic Document Feeder, you can scan up to 30 letter-size pages at a time.


1. Place your document in the Automatic Document Feeder (see page 13).
2. Do one of the following to start Epson Scan:

- **Windows:** Double-click the EPSON Scan icon on your desktop.
- **Macintosh:** Double-click EPSON Scan in the Applications folder.

3. Select **Office Mode** in the upper right.

Select Office Mode

4. Select the **Image Type**.
5. Select **Auto Detect** or **ADF** (Automatic Document Feeder) as the **Document Source** setting.
6. Select the **Size** of the originals and their **Orientation** on the scanner.
7. Select the scanning **Resolution** based on how you will use the scanned image:



- E-mail, view on a computer screen, or post on the web: 96 to 150 dpi
 - Print or convert to editable text (OCR): 300 dpi
 - Fax: 200 dpi
8. Click the **Preview** button to scan and eject the first page. Place the page back on top of the other pages and reload them in the feeder.
 9. If desired, draw a marquee (or box) around the area you want to scan in the Preview window. Adjust the image quality, if necessary.
 10. Click **Scan** and select the name, location, and format (such as PDF) for your scanned document. Then click **OK**. The document is scanned and you see its icon(s) in Windows Explorer or Macintosh Finder.

Note:

Depending on the file format you select, Epson Scan may create one file containing all of the pages in your document or create one file for each page of your document. For more information, see the on-screen *Epson Information Center*.


Maintaining Your All-in-One

Follow the steps here to check and clean the print head, and replace ink cartridges. To align the print head, if necessary, see the on-screen *Epson Information Center*.

Checking the Print Head Nozzles

If your printouts are faint or have gaps in them, the print head nozzles may be clogged. Follow these steps to check the print head nozzles:

1. Load letter-size plain paper in the paper tray.
2. Press the **Home** button, if necessary, and select **Setup**.
3. Select **Maintenance**, then select **Nozzle Check**.
4. Press **Start**.
5. Check the nozzle check pattern that prints to see if there are gaps in the lines:



Nozzles
are clean



Nozzles need
cleaning



6. If there are no gaps, the print head is clean. Select **Finish Nozzle Check**.

If there are gaps or the pattern is faint, select **Head Cleaning**. Then press **Start** to clean the print head.

Cleaning the Print Head

If print quality has declined and the nozzle check indicates clogged nozzles, you can clean the print head. Print head cleaning uses ink, so clean it only if necessary.

Note:

You cannot clean the print head if an ink cartridge is expended, and may not be able to clean it when a cartridge is low. You must replace the cartridge first (see page 59).

1. Load letter-size plain paper in the sheet feeder.
2. Press the **Home** button, if necessary, and select **Setup**.
3. Select **Maintenance**, then select **Head Cleaning**.
4. Press **Start**.



Cleaning takes about 2 minutes. When it's finished, you see a message on the display screen.

Caution:

Never turn off the printer during a cleaning cycle or you may damage it.

5. Select **Nozzle Check**. Then press **Start** to run a nozzle check and confirm that the print head is clean.
6. Select **Finish Nozzle Check** when you're done.

Note:

If you don't see any improvement after cleaning the print head four times, leave your Artisan 800 Series turned on and wait at least six hours to let any dried ink soften. Then try printing again. If you do not use your Artisan 800 Series often, it is a good idea to print a few pages at least once a month to maintain good print quality.


Checking the Ink Cartridge Status


Your Artisan 800 Series will let you know when an ink cartridge is low or expended by displaying a message on its display screen or your computer. You cannot print or copy when an ink cartridge is expended even if the other cartridges are not expended (but you can still scan, fax, and view photos). Replace any expended cartridges before printing or copying.

To check ink cartridge status from the display screen anytime, follow these steps:

1. Press the **Home** button, if necessary, and select **Setup**.

2. Select **Ink Levels**. You see a screen like this:

A cartridge marked with  is getting low on ink. See page 59 to replace the cartridge, if necessary.



3. Press **OK** to exit.

A window may appear on your computer screen when you try to print when ink is low. This window can optionally display ink offers and other updates retrieved from an Epson website. On a Windows or Mac OS X 10.5 computer that is connected to the Internet, you may see a screen asking if you want to receive these Epson offers the first time you try to print when ink is low. Click **Accept** or **Decline**.

Note:

To disable checking for ink offers or updates from Epson, see the instructions in your on-screen *Epson Information Center*.

Purchasing Epson Ink Cartridges

You can purchase genuine Epson ink and paper at Epson Supplies CentralSM at www.epson.com/ink3 (U.S. sales) or www.epson.ca (Canadian sales). You can also purchase supplies from an Epson authorized reseller. To find the nearest one, call 800-GO-EPSON (800-463-7766).

Use the following list when you order or purchase new ink cartridges:

Ink color	Part number	
	High Capacity	Standard Capacity
Black	98	—
Magenta	98	99
Yellow	98	99
Cyan	98	99
Light magenta	98	99
Light cyan	98	99

Note:

High Capacity color ink cartridges are available online only.

We recommend that you use genuine Epson cartridges and do not refill them. The use of other products may affect your print quality and could result in printer damage.

Yields vary considerably based on images printed, print settings, paper type, frequency of use, and temperature. For print quality, a small amount of ink remains in the cartridge after the “replace cartridge” indicator comes on. The printer ships with full cartridges and part of the ink from the first cartridges is used for priming the printer.

For best printing results, use up a cartridge within six months of opening the package.

Store ink cartridges in a cool, dark place. If cartridges were exposed to cold temperatures, allow them to warm up to room temperature for at least 3 hours before using them.

Replacing Ink Cartridges

Make sure you have a new ink cartridge before you begin. You must install new cartridges immediately after removing the old ones.

Caution:

Do not open ink cartridge packages until you are ready to install the ink. Cartridges are vacuum packed to maintain reliability. Leave the expended cartridge(s) installed until you have obtained a replacement, or the ink remaining in the print head nozzles may dry out. If you remove a low or expended cartridge, you cannot reinstall and use it.

1. Turn on the Artisan 800 Series.

If a cartridge is low or expended, you see a message on the display screen. Note which cartridges need to be replaced and press OK. (You cannot print until you have replaced any expended ink cartridges.)


If you're replacing a cartridge before it's expended, follow the steps below.



2. Open the scanner.

Caution:


Make sure the Automatic Document Feeder is closed when you open the scanner.




3. Squeeze the tab on the cartridge and lift it straight up. Dispose of it carefully. Do not take the used cartridge apart or try to refill it.

Warning:

If ink gets on your hands, wash them thoroughly with soap and water. If ink gets into your eyes, flush them immediately with water. Keep ink cartridges out of the reach of children.




4. Remove the cartridge from the package. Do not touch the green chip on the side.




5. Remove the yellow tape from the bottom of the cartridge.

Caution:

Do not remove any other labels or seals, or ink will leak.



6. Insert the new cartridge into the holder and push it down until it clicks into place.



7. Close the scanner.

Note:

If you see a warning message that the cartridge you just replaced is not installed, open the scanner and press down the cartridge securely.

Solving Problems


Check the messages on the display screen to diagnose the cause of most problems. Press the **Home** button, if necessary, and select **Problem Solver**. Press ◀ or ▶ to see all the help topics.

You can also check the basic troubleshooting suggestions starting on page 62 or see the on-screen *Epson Information Center* for more detailed help.

Checking for Software Updates

Periodically, it's a good idea to check Epson's support website for free updates to your Artisan 800 Series software. Open your on-screen *Epson Information Center* and select **Download the Latest Software** or visit Epson's support website at epson.com/support (U.S.) or epson.ca (Canada).



With Windows, you can select **Driver Update** on the Maintenance tab in the printer settings window. You can also click **Start** or , select **Programs** or **All Programs**, select **EPSON**, select **Artisan 800 Series**, and click **Driver Update**. Also select **EPSON Scan** and click the **Scanner Driver Update** for your product.

Problems and Solutions

Check the solutions below if you're having trouble using your Artisan 800 Series.

Note:

If the screen is dark, press the touch panel to wake the printer from sleep mode.

Printing and Copying Problems

- Make sure your paper is loaded printable side down (usually the whiter, brighter, or glossy side). Don't load paper above the edge guides.
- Make sure the type of paper you loaded matches the paper size and paper type settings on the control panel when copying (see page 14), when receiving faxes (see page 25), or when printing with your printer software (see page 49).
- Legal-size documents can be scanned, faxed, or copied using the Automatic Document Feeder. If your copies are cropped, make sure you've loaded legal-size paper in the paper cassette (see page 7).
- Make sure your original is positioned against the back left corner of the scanner glass. If the edges are cropped, move your original away from the edges slightly.



Document Feeding Problems

If documents don't feed correctly in the Automatic Document Feeder, make sure the corners of the paper are not bent, folded, or curled up. Do not load more than 30 letter-size or 10 legal-size sheets at a time. If documents have jammed:

1. Open the ADF cover and pull any paper out to the left.

Caution:

Do not try to remove the paper without opening the ADF cover first.



2. Lift open the ADF and check for any jammed paper underneath.


Paper Feeding Problems

If paper jams when printing, check the following:


1. Open the scanner and remove paper as shown, including any torn pieces.

Caution:


To prevent damage, avoid handling parts inside the printer.



2. Pull back on the tabs to remove the cover inside the Artisan 800 Series. Then remove the paper as shown, including any torn pieces.



3. Reattach the cover and close the scanner.



4. You may also need to check other locations for jammed paper, such as the back cover or auto duplexer (if installed), the paper cassette, and underneath the printer. See the on-screen *Epson Information Center* for more information.

Faxing Problems

- Make sure the recipient's fax machine is turned on and working.
- Make sure the **LINE** port on the Artisan 800 Series is connected to a telephone wall jack. Verify that the telephone wall jack works by connecting a phone to it.
- If the line has static, press the **Home** button and select **Setup**. Select **Fax Setting**, then select **Communication**. Turn off the **V.34** and **ECM** (Error Correction Mode) settings.
- If the Artisan 800 Series is connected to a DSL phone line, you must have a DSL filter connected to the phone jack. Contact your DSL provider for the necessary filter.
- If fax calls are disconnected when you hang up, make sure a phone or answering machine is connected to the **EXT.** port.
- If an answering machine is connected, set the number of rings to answer for receiving faxes to be greater than the number of rings for the answering machine.

Print Quality Problems

- For the best print quality, use Epson papers (see page 10) and genuine Epson ink cartridges (see page 59).
- If you notice light or dark bands across your printouts or they are too faint, run a nozzle check (see page 55) to see if the print head needs cleaning.
- If you notice jagged vertical lines, you may need to align the print head. See the on-screen *Epson Information Center* for instructions.
- The ink cartridges may be low on ink. Check your cartridge status (see page 57) and replace cartridges, if necessary (see page 59).
- If you're copying, place the document flat against the scanner glass.
- Clean the scanner glass with a soft, dry, lint-free cloth (paper towels are not recommended), or use a small amount of glass cleaner on a soft cloth, if necessary. Do not spray glass cleaner directly on the glass.

Where To Get Help

Epson Technical Support

Internet Support

Visit Epson's support website at epson.com/support and select your product for solutions to common problems. You can download drivers and documentation, get FAQs and troubleshooting advice, or e-mail Epson with your questions.

Speak to a Support Representative

Before you call Epson for support, please have the following information ready:

- Product name (Artisan 800 Series)
- Product serial number (on the back of the Artisan 800 Series or under the scanner unit)
- Proof of purchase (such as a store receipt) and date of purchase
- Computer configuration and description of the problem

Then call:

- U.S.: (562) 276-4382, 6 AM – 6 PM, Pacific Time, Monday through Friday
- Canada: (905) 709-3839, 6 AM – 6 PM, Pacific Time, Monday through Friday

Days and hours of support are subject to change without notice. Toll or long distance charges may apply.

Purchase Supplies and Accessories

You can purchase genuine Epson ink, paper, and accessories at Epson Supplies Central at www.epson.com/ink3 (U.S. sales) or www.epson.ca (Canadian sales). You can also purchase supplies from an Epson authorized reseller. To find the nearest one, call 800-GO-EPSON (800-463-7766).

Other Software Technical Support

ArcSoft Print Creations
www.arcsoft.com/support

ABBYY FineReader Sprint Plus
Phone: (510) 226-6717
www.abbyyusa.com
support@abbyyusa.com

Notices

Important Safety Instructions

Before using your all-in-one, read and follow these safety instructions:

- Be sure to follow all warnings and instructions marked on the product.
- Use only the type of power source indicated on the product label.
- Use only the power cord that comes with the product. Use of another cord may cause fires or shock. Do not use the cord with any other equipment.
- Place the product near a wall outlet where the plug can be easily unplugged.
- If you won't be using the product for a long period, unplug the power cord from the electrical outlet.
- Always turn off the product using the ⏻ On button, and wait until the ⏻ On light stops flashing before unplugging the printer or cutting off power to the electrical outlet.
- Avoid plugging the product into an outlet on the same circuit as a photocopier or air conditioning system that regularly switches on and off, or on an outlet controlled by a wall switch or timer.
- Do not let the power cord become damaged or frayed.
- If you use an extension cord with the product, make sure the total ampere rating of the devices plugged into the extension cord does not exceed the cord's ampere rating. Also, make sure the total ampere rating of all devices plugged into the wall outlet does not exceed the wall outlet's ampere rating.
- Place the product on a flat, stable surface that extends beyond its base in all directions. It will not operate properly if it is tilted or at an angle.
- When storing or transporting the product, do not tilt it, stand it on its side, or turn it upside down; otherwise ink may leak from the cartridges.
- Avoid placing the product in locations that are subject to rapid changes in heat or humidity, shocks or vibrations, or dust.
- Leave enough room around the product for sufficient ventilation. Make sure the product is at least 4 inches (10 cm) away from the wall.
- Do not place the product near a radiator or heating vent or in direct sunlight.
- Do not block or cover openings in the product case or insert objects through the slots.

- Do not use aerosol products that contain flammable gases inside or around the printer. Doing so may cause fire.
- Do not press too hard on the document table when placing the originals.
- Do not open the scanner section while the product is in use.
- Do not touch the flat white cable inside the product.
- Do not spill liquid on the product.
- Adjust only those controls that are covered by the operating instructions. Except as specifically explained in your documentation, do not attempt to service the product yourself.
- Unplug the product and refer servicing to qualified service personnel under the following conditions: if the power cord or plug is damaged; if liquid has entered the product; if the product has been dropped or the case damaged; if the product does not operate normally or exhibits a distinct change in performance.
- The cords included with this product contain chemicals, including lead, known to the State of California to cause birth defects or other reproductive harm. ***Wash hands after handling.*** (This notice is provided in accordance with Proposition 65 in Cal. Health & Safety Code § 25249.5 and following.)

LCD Screen Safety

- Use only a dry, soft cloth to clean the LCD screen. Do not use liquid or chemical cleansers.
- If the LCD screen is damaged, contact Epson. If the liquid crystal solution gets on your hands, wash them thoroughly with soap and water. If the liquid crystal solution gets into your eyes, flush them immediately with water. If discomfort or vision problems remain after a thorough flushing, see a doctor immediately.

Ink Cartridge Safety Instructions

- Keep ink cartridges out of the reach of children and do not drink the ink.
- Be careful when you handle used ink cartridges; there may be ink remaining around the ink supply port. If ink gets on your skin, wash it off with soap and water. If it gets in your eyes, flush them immediately with water. If you still have discomfort or vision problems, see a doctor immediately.
- Do not put your hand inside the product or touch any cartridges during printing.
- Install a new ink cartridge immediately after removing an expended one. Leaving cartridges uninstalled can dry out the print head and may prevent the product from printing.

- If you remove an ink cartridge for later use, protect the ink supply area from dirt and dust and store it in the same environment as the product. Note that there is a valve in the ink supply port, making covers or plugs unnecessary, but care is needed to prevent the ink from staining items that the cartridge touches. Do not touch the ink cartridge ink supply port or surrounding area. Do not store the cartridge upside down.

Telephone Equipment Safety Instructions

When using telephone equipment, you should always follow basic safety precautions to reduce the risk of fire, electric shock, and personal injury, including the following:

- Do not use the Epson product near water.
- Avoid using a telephone during an electrical storm. There may be a remote risk of electric shock from lightning.
- Do not use a telephone to report a gas leak in the vicinity of the leak.

Caution:

To reduce the risk of fire, use only a No. 26 AWG or larger telecommunication line cord.

Epson America, Inc., Limited Warranty

What Is Covered: Epson America, Inc. (“Epson”) warrants to the original retail purchaser that the Epson printer covered by this limited warranty statement, if purchased and operated only in the United States or Canada, will be free from defects in workmanship and materials for the warranty period, as measured from the date of original purchase. The “warranty period” means two years, if you registered your printer purchase with Epson within 60 days of purchase, and one year otherwise. For residents of California or Quebec, failure to submit the product registration form does not diminish your warranty rights. For warranty service, you must provide proof of the date of original purchase.

This limited warranty statement also covers any Epson-branded duplexer purchased separately for use with the printer. The warranty period for your duplexer is the same as the period for your printer. In this limited warranty statement, the “product” means the printer and the duplexer.

What Epson Will Do To Correct Problems: Should your Epson printer prove defective during the warranty period, please call the Epson ConnectionSM at (562) 276-4382 (U.S.) or (905) 709-3839 (Canada) for warranty repair instructions and return authorization. An Epson service technician will provide telephone diagnostic service to determine whether the printer requires service. If service is needed, Epson will, at its option, exchange or repair the printer without charge for parts or labor. If Epson authorizes an exchange for the defective unit, Epson will ship a replacement printer to you, freight prepaid, so long as you use an address in Canada or the U.S. (excluding Puerto Rico and U.S. Possessions).

Shipments to other locations will be made freight collect. You are responsible for securely packaging the defective unit and returning it to Epson within five (5) working days of receipt of the replacement. Epson requires a debit or a credit card number to secure the cost of the replacement printer in the event that you fail to return the defective one. If Epson authorizes repair instead of exchange, Epson will direct you to send your printer to Epson or its authorized service center, where the printer will be repaired and sent back to you. You are responsible for packing the printer and for all costs to and from the Epson authorized service center. When warranty service involves the exchange of the printer or a part, the item replaced becomes Epson property. The replacement printer or part may be new or refurbished to the Epson standard of quality, and, at Epson's option, may be another model of like kind and quality. Exchange products and parts assume the remaining warranty period of your original product covered by this limited warranty.

What This Warranty Does Not Cover: This warranty covers only normal use in the United States and Canada. Using this product for continuous production or similar high duty purposes is not considered normal use; damage, maintenance or service from such use will not be covered under this warranty. This warranty is not transferable. This warranty does not cover any color change or fading of prints or reimbursement of materials or services required for reprinting. This warranty does not cover damage to the Epson product caused by parts or supplies not manufactured, distributed or certified by Epson. This warranty does not cover ribbons, ink cartridges or third party parts, components, or peripheral devices added to the Epson product after its shipment from Epson, e.g., dealer or user-added boards or components. Epson is not responsible for warranty service should the Epson label or logo or the rating label or serial number be removed or should the product fail to be properly maintained or fail to function properly as a result of misuse, abuse, improper installation, neglect, improper shipping, damage caused by disasters such as fire, flood, and lightning, improper electrical current, software problems, interaction with non-Epson products, or service other than by an Epson Authorized Servicer. If a claimed defect cannot be identified or reproduced, you will be held responsible for the costs incurred.

THE WARRANTY AND REMEDY PROVIDED ABOVE ARE EXCLUSIVE AND IN LIEU OF ALL OTHER EXPRESS OR IMPLIED WARRANTIES INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT OR FITNESS FOR A PARTICULAR PURPOSE. SOME LAWS DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES. IF THESE LAWS APPLY, THEN ALL EXPRESS AND IMPLIED WARRANTIES ARE LIMITED TO THE WARRANTY PERIOD IDENTIFIED ABOVE. UNLESS STATED HEREIN, ANY STATEMENTS OR REPRESENTATIONS MADE BY ANY OTHER PERSON OR FIRM ARE VOID. IN NO EVENT SHALL EPSON OR ITS AFFILIATES BE LIABLE FOR ANY SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OR INABILITY TO USE THE EPSON PRODUCT, WHETHER RESULTING FROM BREACH OF

WARRANTY OR ANY OTHER LEGAL THEORY. IN NO EVENT SHALL EPSON OR ITS AFFILIATES BE LIABLE FOR DAMAGES OF ANY KIND IN EXCESS OF THE ORIGINAL RETAIL PURCHASE PRICE OF THE PRODUCT.

In Canada, warranties include both warranties and conditions.

Some jurisdictions do not allow limitations on how long an implied warranty lasts, and some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations and exclusions may not apply to you. This warranty gives you specific legal rights and you may have other rights which vary from jurisdiction to jurisdiction.

To find the Epson Authorized Reseller nearest you, visit our website at:
<http://www.epson.com>.

To find the Epson Customer Care Center nearest you, visit
<http://www.epson.com/support>.

You can also write to:

Epson America, Inc., P.O. Box 93012, Long Beach, CA 90809-3012

Declaration of Conformity

According to 47CFR, Part 2 and 15 for: Class B Personal Computers and Peripherals; and/or CPU Boards and Power Supplies used with Class B Personal Computers:

We: Epson America, Inc.
Located at: MS 3-13
3840 Kilroy Airport Way
Long Beach, CA 90806
Telephone: (562) 290-5254

Declare under sole responsibility that the product identified herein, complies with 47CFR Part 2 and 15 of the FCC rules as a Class B digital device. Each product marketed is identical to the representative unit tested and found to be compliant with the standards. Records maintained continue to reflect the equipment being produced can be expected to be within the variation accepted, due to quantity production and testing on a statistical basis as required by 47CFR §2.909. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Trade Name: Epson
Type of Product: Multifunction printer
Model: C381A

FCC Compliance Statement

For United States Users

This equipment complies with Part 68 of the FCC rules and the requirements adopted by the ACTA. On the back side is a label that contains, among other information, the FCC registration number and the **ringer equivalence number (REN)** for this equipment. You must, upon request, provide this information to your local telephone company. The information associated with the services the equipment is to be connected are REN: **0.1B**, Jack type: **RJ-11C**.

The REN is useful to determine the quantity of devices that you may connect to your telephone line and still have all of those devices ring when your telephone number is called. In most, but not all areas, the sum of the RENs of all devices connected to one line should not exceed five (5.0). To be certain of the number of devices that you may connect to your line, you may want to contact your local telephone company to determine the maximum REN for your calling area. For products approved after July 23, 2001, the REN for this product is part of the product identifier that has the format **US:**

BKMFA01BC381A. The digits represented by 00 are the REN without a decimal point (e.g., 00 is a REN of 0.0). For earlier products, the REN is separately shown on the label.

This equipment may not be used on coin service provided by the telephone company. Connection to party lines is subject to state tariffs.

Should this equipment cause harm to the telephone network, the telephone company may discontinue your service temporarily. If possible they will notify you in advance that temporary discontinuance of service may be required. But if advanced notice isn't practical, the telephone company will notify you as soon as possible. You will be informed of your right to file a complaint with the FCC. The telephone company may make changes in its facilities, equipment, operations or procedures that could affect the proper functioning of your equipment. If they do, you will be notified in advance to give you an opportunity to maintain uninterrupted telephone service.

This product is not intended to be repaired. If you experience trouble with this equipment, please contact:

Name: Epson America, Inc.
Address: 3840 Kilroy Airport Way, Long Beach, CA 90806 U.S.A.
Telephone: (562) 981-3840

The telephone company may ask that you disconnect this equipment from the network until the problem has been corrected or until you are sure that the equipment is not malfunctioning.

A plug and jack used to connect this equipment to the premises wiring and telephone network must comply with the applicable FCC Part 68 rules and requirements adopted by the ACTA. A compliant telephone cord and modular plug is provided with this product. It is designed to be connected to a compatible modular jack that is also compliant. See installation instructions for details.

The Telephone Consumer Protection Act of 1991 makes it unlawful for any person to use a computer or other electronic device, including fax machines, to send any message unless such message clearly contains in a margin at the top or bottom of each transmitted page or on the first page of the transmission, the date and time it is sent and an identification of the business or other entity, or other individual sending the message and the telephone number of the sending machine or such business, other entity, or individual. In order to program this information into your fax machine, follow the instructions in “Entering Fax Header Information” on page 20.

According to the FCC’s electrical safety advisory, we recommend that you may install an AC surge arrestor in the AC outlet to which this equipment is connected. Telephone companies report that electrical surges, typically lightning transients, are very destructive to customer terminal equipment connected to AC power sources and that this is a major nationwide problem.

If your home has specially wired alarm equipment connected to the telephone line, ensure the installation of this equipment Model C381A does not disable your alarm equipment. If you have questions about what will disable alarm equipment, consult your telephone company or a qualified installer.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio or television reception. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause interference to radio and television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

WARNING

The connection of a non-shielded equipment interface cable to this equipment will invalidate the FCC Certification of this device and may cause interference levels which exceed the limits established by the FCC for this equipment. It is the responsibility of the user to obtain and use a shielded equipment interface cable with this device. If this equipment has more than one interface connector, do not leave cables connected to unused interfaces. Changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.

For Canadian Users

1. This product meets the applicable Industry Canada technical specifications.

Le présent matériel est conforme aux spécifications techniques applicables d'Industrie Canada.

2. The Ringer Equivalence Number is an indication of the maximum number of devices allowed to be connected to a telephone interface. The termination on an interface may consist of any combination of devices subject only to the requirement that the sum of the RENs of all the devices does not exceed five.

L'indice d'équivalence de la sonnerie (IES) sert à indiquer le nombre maximal de terminaux qui peuvent être raccordés à une interface téléphonique. La terminaison d'une interface peut consister en une combinaison quelconque de dispositifs, à la seule condition que la somme d'indices d'équivalence de la sonnerie de tous les dispositifs n'excède pas 5.

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

Index

A

- ABBYY FineReader software, 52, 65
- Accessories, purchasing, 65
- ADF, *see* Automatic Document Feeder
- Adjusting color in photos, 30
- Aligning print head, 55
- ArcSoft Print Creations software, 43, 65
- Auto Answer button, 25
- Auto Correction for photos, 29 to 30
- Auto Reduction setting, faxing, 22
- Automatic Document Feeder
 - capacity, 13, 62
 - placing documents in, 13
 - scanning, 54

B

- Black-and-white copying, 14, 17
- Borderless
 - copying, 17
 - printing, 46, 47

C

- Calendar, personalized, 43
- Camera
 - connecting, 33
 - printing from, 33 to 34
- Capacity, *see* Loading capacity
- CD/DVD
 - creating label, 39 to 42
 - density setting, 41
 - ink drying time, 42
 - jewel case insert, 39
 - placing on tray, 41
 - removing from tray, 42

- Cleaning
 - print head, 56
 - scanner glass, 64
- Clear Settings button, 6
- Color in photos
 - adjusting, 30
 - restoring, 15, 17
- Coloring book pages, 35 to 36
- Computer, printing from, 43 to 51
- Contrast setting, faxing, 21
- Control panel
 - raising and lowering, 5
 - using, 5 to 6
- Copying
 - black-and-white, 14, 17
 - borderless photos, 17
 - density setting, 14
 - documents, 14 to 15
 - photos, 15 to 17
 - placing documents, 12
 - problems, 62
 - restoring color, 15
 - using the ADF, 13
- Cropping a photo, 16

D

- Date and time settings, 20
- Density adjustment
 - CD/DVD label, 41
 - copying, 14
 - two-sided printing, 51
- Dialing to send a fax, 24
- Digital camera, *see* Camera
- Displaying multiple photos, 30

Documents
 copying, 14 to 15
 placing in ADF, 13
 placing on scanner, 12
Double-sided printing, *see* Two-sided printing
Drying time of ink
 CD/DVD, 42
 two-sided printing, 51
DSL filter, 18, 64
Duplexer
 checking for paper jams, 63
 printing with, 50 to 51
 purchasing, 65

E

Envelopes
 loading, 10
 paper type setting, 49
Epson
 help, 65
 ink cartridges, 58
 ink offers, 57
 papers, 10 to 11
 purchasing from, 65
 warranty, 68 to 70
Epson Print CD software, 39
Epson Scan software, 52 to 54

F

Faded photos, restoring, 15, 17
Faxing
 ADF, using, 13, 23 to 24
 auto answer, 25
 Auto Reduction setting, 22
 connecting phone line, 18 to 19
 contrast, 21
 date and time settings, 20
 dialing number, 24
 entering phone number, 20 to 21, 23
 feature setup, 19 to 23

Faxing (continued)
 group dial, 22 to 23, 24
 header, 20
 international number, 20
 keypad, 21, 23
 paper size, 21
 placing documents, 12, 23 to 24
 printing reports, 19, 22
 problems, 64
 receiving a fax, 19, 25
 redialing, 24
 resolution, 21
 rings to answer, 19, 25
 scan and print settings, 21 to 22
 sender name and phone number, 20
 sending a fax, 23 to 24
 settings, 19 to 23
 speed dial, 22 to 23, 24
File format
 memory card, 27, 33
 scanning, 53, 54
FineReader software, 52, 65
Fix Photo setting, 30

G

Group dial
 printing list, 23
 setting up, 22
 using, 24

H

Head cleaning, *see* Print head
Header, fax, 20
Help, 61, 65
Home button, 6

I

Icons on screen, 6

Ink cartridges

- checking status, 57
- offers from Epson, 57
- part numbers, 58
- purchasing, 58, 65
- replacing, 59 to 60
- safety, 67 to 68
- storage, 58

Ink drying time, *see* Drying time of ink

Ink levels, 57

Inserting memory card, 26 to 27

Inserting USB drive, 28

J

Jam, paper, 62 to 63

Jewel case insert, printing, 39

JPEG file format, 27, 33

K

Keypad, using, 21, 23

L

Label, CD/DVD, 39 to 42

Layout sheets, printing, 31 to 32

LCD Screen, *see* Touch panel

Legal-size paper, loading, 10

Lined paper, printing, 37

Loading capacity

- ADF, 13, 62

- paper cassette, 7

Loading paper, 7 to 10

M

Macintosh

- borderless printing, 46, 47
- monitoring print job, 47, 49
- OS X 10.3 and 10.4, 47 to 49, 51
- OS X 10.5 (Leopard), 45 to 47, 51
- printing, 45 to 49, 51
- two-sided printing, 51

Maintenance

- aligning print head, 55
- checking ink cartridge status, 57
- checking print head, 55
- cleaning print head, 56
- cleaning scanner glass, 64
- replacing ink cartridges, 59 to 60

Media type setting, 49

Memory card

- access light, 27
- file format, 27, 33
- inserting, 26 to 27
- removing, 27
- selecting photos and printing from, 29 to 30
- slots, 26 to 27
- types, 26

Menu button, 6

Modes for scanning, 52, 53

Monitoring print job, 45, 47, 49

N

Note paper, personalized, 37 to 39

Notebook paper, 37

Nozzle check pattern, 55

O

OCR (optical character recognition)
software, 52, 65

P

Paper

- jams, 62 to 63
- loading, 7 to 10
- loading capacity, 7
- purchasing, 10, 65
- types, 10 to 11, 49

Paper Size setting, faxing, 21

Paper type setting, 49

Personalized note paper, 37 to 39

Phone line, connecting, 18 to 19

Phone number in fax header, 20

Photo greeting cards, 43

Photo paper

- loading, 9
- purchasing, 10
- types, 10 to 11

Photos

- adjusting color, 30
- Auto Correction, 29 to 30
- borderless, 17, 46, 47
- copying, 15 to 17
- cropping, 16
- displaying multiple photos, 30
- faded, 15, 17
- file format, 27, 33
- layout sheets, 31 to 32
- placing on scanner, 12
- red-eye reduction, 30, 44, 46
- restoring color, 15, 17
- selecting and printing, 29 to 34
- templates, 31 to 32

PictBridge, 33

Print Creations software, 43, 65

Print head

- alignment, 55
- checking, 55
- cleaning, 56

Print job, monitoring, 45, 47, 49

Print quality

- maintaining, 55 to 56
- problems, 64

Printer software updates, 61

Printing

calendar, 43

CD/DVD label, 39 to 42

coloring book pages, 35 to 36

duplexing, 50 to 51

fax report, 19, 22

from a camera, 33 to 34

from a computer, 43 to 51

jewel case insert, 39

layout sheets, 31 to 32

lined (ruled) paper, 37

Macintosh, 45 to 49, 51

personalized note paper, 37 to 39

photo greeting cards, 43

photos, 29 to 34

problems, 62, 64

shortcut settings, 44

special projects, 35 to 42, 43

two-sided pages, 50 to 51

Windows, 43 to 45, 50 to 51

Purchasing ink and paper, 10, 58

R

Receiving faxes, 19, 25

Red-eye reduction, 30, 44, 46

Redial, 24

Removing memory card, 27

Replacing ink cartridges, 59 to 60

Report, fax, 19, 22

Resolution setting

faxing, 21

scanning, 54

Restoring photos, 15, 17

Rings to Answer setting, 19, 25

Ruled paper, printing, 37

S

Safety instructions

- general, 66 to 67
- ink cartridge, 67 to 68
- telephone equipment, 68
- touch panel, 67

Scanner

- Automatic Document Feeder, 13
- cleaning, 64
- document glass, 12
- software updates, 61

Scanning

- Epson Scan software, 52 to 54
- file format, 53, 54
- modes, 52, 53
- multiple pages, 54
- OCR software, 52, 65
- placing documents, 12
- resolution, 54
- TWAIN-compliant application, 52
- using the ADF, 13, 54

Screen, *see* Touch panel

Sender name in fax header, 20

Sending faxes, 23 to 24

Shortcut settings, 44

Sleep mode, 6, 62

Software

- ABBYY FineReader, 52, 65
- ArcSoft Print Creations, 43, 65
- Epson Print CD, 39
- Epson Scan, 52 to 54
- OCR (optical character recognition), 52, 65
- support, 65
- updates, 61

Special projects

- calendars, 43
- CD/DVD labels, 39 to 42
- coloring book pages, 35 to 36
- graph paper, 37
- layout sheets, photo, 31 to 32
- lined (ruled) paper, 37
- note paper, personalized, 37 to 39
- photo greeting cards, 43

Speed dial

- printing list, 23
- setting up, 22
- using, 24

Status light, 6

Storing ink cartridges, 58

Support

- Epson, 65
- software, 65

Symbols on screen, 6

T

Templates, photo, 31 to 32

Touch panel

- icons, 6
- raising and lowering, 5
- safety, 67
- sleep mode, 6, 62
- using, 5 to 6

Troubleshooting

- copying problems, 62
- faxing problems, 64
- paper problems, 62 to 63
- print quality problems, 64
- printing problems, 62

Two-sided printing

- density setting, 51
- ink drying time, 51
- Macintosh, 51
- Windows, 50 to 51

U

Unlock button, 5

USB drive, inserting, 28

V

View Auto Correct setting, 29

W

Warranty, 68 to 70

Windows

- monitoring print job, 45

- printing from, 43 to 45, 50 to 51

- shortcut settings, 44

- two-sided printing, 50 to 51

