

EPSON PRODUCT SUPPORT BULLETIN

Date:	04/09/2007	Originator:	esc
PSB #:	PSB.2007.04.002	Authorization:	Kps
Reference:	TE06-0866 Rev. A	Total Pages:	1
Product(s):	P-2000 and P-4000 Multimedia Storage Viewers		
Subject:	Compatibility issues with Lexar Media Compact Flash Memory Cards		

This bulletin was created to inform you of compatibility issues occurring with the Lexar Media 1GB/2GB Compact Flash memory cards on the P-2000 and P-4000 Multimedia Storage Viewers.

The following issues may occur when using the Lexar Media Professional series CF memory cards or the Lexar Platinum II series memory CF cards as shown below.

Error conditions:

- The card is not recognized.
- The data back-up thumbnails are not displayed.
- Displays the data back-up thumbnails, but some pictures are not correctly displayed.

- **Lexar Professional 133x 1GB, 2GB**



- **Lexar Platinum II 80x**



Note:

If you encounter any of the errors listed above, please try a Compact Flash memory card from a different manufacturer.

EPSON Product Support Bulletin

Date:	12/12/2005	Originator:	JD
PSB #:	PSB.2005.12.001	Authorization:	<i>Kps</i>
Reference:	TE05-0578 Rev. A	Total Pages:	4
Product(s):	Epson P-4000 Multimedia Storage Viewer		
Subject:	New Firmware Release version 04.51		

This bulletin was created to inform you of a firmware update for the P-4000 multimedia viewer. The updated firmware provides certain upgrades as outlined below.

Description of Change:

The firmware has been updated to version **04.51**.

Reason:

The firmware provides the following upgrades:

1. The new firmware provides support for 2GB SD memory cards.
2. Corrects a rotation issue that prevents JPEG images taken on PENTAX *ist D digital cameras from being rotated more than once. The rotation issue may also occur on other digital cameras that store large amounts of data (i.e. image thumbnail and other proprietary information) in the file header, such as the PENTAX *ist DL and Canon EOS 10D.
3. When sending a print job with a selected paper size that is not supported by the attached printer, the viewer will prompt the user to select a supported paper size.
4. Fixes an issue that occurs when the total replay time on an ASF movie file is displayed. When the seconds segment is set to zero (:00), the hour segment would be displayed incorrectly. The hour segment now displays correctly.

P-4000 Firmware Update Instructions:

Note: Before starting the firmware update process, confirm that there are no files on the Memory Card.

To download and install the new firmware file, you will need the following:

- Windows-based PC or Macintosh computer with Internet access
- Operating Systems: Windows 98/ME/2000/XP Home/Pro
- Operating Systems: Macintosh 9.1-9.2.2, OS 10.2 to 10.4.x
- Memory Card Reader/Writer
- 128MB or higher formatted Compact Flash or SD memory card (there must be no data on the card)
- P-4000 battery installed (fully-charged battery recommended)
- AC Adapter – the firmware update must be performed with the unit powered by its AC power adapter.

Firmware Update Procedure:

Download the file **epson11718.exe** for Windows or **epson11719.sea.hqx** (Mac OS 9.x) / **epson11720.dmg** (Mac OS X) from the Epson website.

To verify the firmware version, power on the unit, select Settings in the Home Menu and press the OK button. The firmware version is located in the lower right-hand corner of the screen, as shown below.




See above picture. Updated version number will be displayed

Steps:


1. Install a **blank** memory card into a Memory Card Reader/Writer and copy the "PSVFIRM2" folder (including all the files in the folder) to the root directory of the memory card.
2. Verify that the battery is installed in the P-4000
3. Connect the AC adapter to the P-4000, **but do not power on the unit.**
4. After the firmware file has been downloaded to the memory card, insert the CompactFlash or SD memory card into the P-4000 as shown below.



5. Press and hold down the “OK” button while sliding the “POWER” switch as shown below.




Release the Power switch and continue holding down the OK button until the message below appears on the screen. **Note:** If you do not see this screen, power off the unit and start the firmware process again.



During the update process, the message screen will display the current firmware and updated firmware versions. Then the message “Updating Resources” will appear.

Important: Do not remove the battery or disconnect the AC adapter during the firmware update process.

- The firmware process is completed when you see the message “Resources Updated Successfully” displayed on the screen.



- When you see the message “Shutdown Restart Device”, power off the unit and remove the CompactFlash or SD memory card.
- When you power on the unit, you will be prompted to select the language and set the date and time. To confirm the new firmware version, select Settings in the Home Menu. The firmware version is located on the lower right side of the screen. It should say **04.51**.

