

Installing EPSON® Printer Software on Windows® Millennium Edition

If you're connecting your printer to a computer running Microsoft® Windows Millennium Edition (Me), follow the steps below to install your printer software. **Don't follow the standard Windows software installation instructions on the *Start Here* sheet.**

- 1 Follow the instructions on the *Start Here* sheet to unpack your printer, put on the paper support, install ink cartridges, load paper, and connect the printer to your computer. Then return here for instructions on installing your printer software.
- 2 Turn on your computer.
- 3 Turn on your printer.
- 4 If you see this screen, your printer software is already installed. Click **OK**.

(If you see a different screen, see step 5.)




Now select your printer as the Windows default printer. Click **Start**, point to **Settings**, and click **Printers**. Right-click your printer icon and click **Set as Default** in the menu that appears.

Now you're ready to print!

Be sure to return to the back of the *Start Here* sheet to install your creative software and EPSON documentation.

Click **Set As Default**







- 5 If you see this screen instead, click **Cancel** and follow the instructions on the back of this sheet to install your printer software.





Click **Cancel** . . .
then turn over this sheet



Installing Your Printer Software

- 1 Turn OFF your printer (the  power light should be OFF). It's important to turn OFF your printer and wait for the installation program to tell you when to turn it on.**
- 2 Insert your printer software CD-ROM in a CD-ROM or DVD drive.
- 3 Double-click the  **My Computer** icon on your desktop, then double-click the  **EPSON** CD-ROM icon.
- 4 Double-click the  **EPSON** icon to start the installer. Read the license agreement and click **Agree**. You see the Main Menu.
- 5 Click **Install Printer Driver**. You see the printer driver installation screen. Click **OK**. The installer copies files to your computer.
- 6 **When you see this screen, turn ON your printer.** The screen disappears and installation continues.
- 7 When installation is finished, click **OK**.
- 8 You see the EPSON Product Registration screen. Follow the on-screen instructions to register your printer with EPSON. At the last screen, click **Done**.
- 9 Return to the back of the *Start Here* sheet to install your creative software and EPSON documentation.



If you connected your printer with a parallel interface cable, you may want to restart your computer now.