# Start Here

410980600

## 1 Unpack

Unpack and remove protective tape.

2 Install software

Do not connect the USB cable yet.

Epson Perfection V200 Photo
Software Installation

This CD-ROM has all the software and information you need for scanning.
Click the Install button to get started.

- ⊠ EPSON Scan
- ⊠ EPSON Creativity Suite
- ⊠ ArcSoft PhotoImpression 6
- ⊠ ABBYY FineReader 6.0 Sprint
- ⊠ User's Guide
- ⊠ Adobe Reader

If you need to reinstall individual items, click Custom.

EPSON   Custom   Install   Exit

Click **Install** and follow the on-screen instructions.

Windows Vista™: Click **Run Epsetup.exe** when prompted.

## 3 Connect and turn on

1

2 Plug the AC adapter into an electrical outlet.

3

4

Press the ⏻ Power button. Do not press any buttons while the status light is flashing.

**Note:** To turn off the scanner press and hold the ⏻ Power button for 3 seconds.

4 Scan a photo

Press the ✔ Start button.

EPSON Scan
Mode: Full Auto Mode

Scan
To scan in Full Auto Mode, position or load the material you want to scan, then click Scan.

Customize
For Color Restoration and other options, click the Customize button and then make the settings.

☑ Show this dialog box before next scan.

ⓘ You can change the scan mode in the Mode list box at the top right of the window.

Help
Close

Click **Scan**.

EPSON Scan
Mode: Full Auto Mode

Preview and document type recognition is in progress.

Pause

Epson Scan scans your photo in **Full Auto Mode**. Wait for your scan to finish.

C:\Documents and Settings\User\My Documents\My Pictures

File   Edit   View   Favorites   Tools   Help

Back   Search   Folders

Picture Tasks
- Get pictures from camera or scanner
- View as a slide show
- Order prints online
- Print pictures
- Copy all items to CD

File and Folder Tasks

Other Places
- My Documents
- Shared Pictures
- My Computer
- My Network Places

**Details**

Desktop.ini   Sample Pictures   img007.jpg

View your photo in **Pictures** or **My Pictures**.

💡 Do more

Scan film

Insert negatives with the shiny side facing down.

Press the ◇ Start button and follow the rest of the steps in section 4 "Scan a Photo."

Scan slides

Press the ◇ Start button and follow the rest of the steps in section 4 "Scan a Photo."

Restore color

You can also optimize your scans with the Enhanced Backlight Correction and Digital Dust Removal features. See your on-screen *User's Guide* for details.

? Help

Scanner Software Help
Click the **Help** button on your scanner software screen.

User's Guide
Double-click the **Perfection V200P User's Guide** icon on your desktop.

Epson Technical Support
Internet Support
Visit Epson's support website at **epson.com/support** and select your product for solutions to common problems for the Perfection V200 Photo. You can download drivers and documentation, get FAQs and troubleshooting advice, or e-mail Epson with your questions.

Speak to a Support Representative
U.S.: (562) 276-4382, 6 AM to 6 PM, Pacific Time, Monday through Friday

Canada: (905) 709-3839, 6 AM to 6 PM, Monday through Friday

Toll or long distance charges may apply.

Software Technical Support
ArcSoft PhotoImpression®: Phone (510) 440-9901, Fax (510) 440-1270, www.arcsoft.com, support@arcsoft.com

ABBYY® FineReader®: (510) 226-6717, www.abbyyusa.com, support@abbyyusa.com

---

EPSON®
EXCEED YOUR VISION

Epson is a registered trademark and Exceed Your Vision is a trademark of Seiko Epson Corporation. Perfection is a registered trademark of Epson America, Inc.
General Notice: Other product names used herein are for identification purposes only and may be trademarks of their respective owners. Epson disclaims any and all rights in those marks.
© 2007 Epson America Inc. 3/07 CPD-23664
Printed in : XXXXXX XX.XX-XX XXX

ENERGY STAR