

README_ENGLISH.TXT

EPSON RC+ 7.0
Version 7.0.4

Copyright (c) 1994-2013
SEIKO EPSON CORPORATION, INC.

Installation Notes

=====

1. EPSON RC+ 7.0.4 can be installed on the following operating systems:

Windows XP Professional with Service Pack 3.
Windows Vista Business with Service Pack 2.
Windows 7 Professional

2. You must be logged in as Administrator to install.
3. To install:
 - a. Insert the EPSON RC+ 7.0 installation DVD.
 - b. The setup program will start automatically.
 - c. If setup doesn't start, run e:\EpsonRC60\setup.exe where e: is the DVD drive.
 - d. Follow the instructions on the screen.
4. During installation, Microsoft .NET Framework 3.5 will be installed if not found.
5. During installation, Adobe Reader will be installed if not found.
6. When you reboot the system for the first time after installation, you must use the same login name that you used for installation. This is so that system files are updated properly.

Getting Started

=====

After installation, there will be a program group called "EPSON RC+ 7.0". A desktop shortcuts are created.

To start EPSON RC+ 7.0, either double click on of the desktop shortcuts or click Start, then select EPSON RC+ 7.0.

The very first time you run EPSON RC+, no projects will be open. You must create a new project by selecting New Project from the Project menu. By default, the next time you run EPSON RC+, the last project you were working on will be opened automatically.

Getting Help

=====

EPSON RC+ has context sensitive help. Press the F1 key at any time to get help for the current operation, or click on the ? button for the current dialog box.

You can get help for SPEL+ language keywords in the Edit window by placing the insertion point anywhere within a keyword and pressing the F1 key.

You can also select Contents from the Help menu to open the Help table of contents. First time users should review the Introduction in the help contents.