


Upgrading Your Epson® P-2000

To take advantage of the latest enhancements for your P-2000, you may be able to upgrade your viewer's firmware. To find out if you have the latest firmware, turn on your P-2000, go to the Home screen, and click the Settings icon.

The firmware version is located in the lower-right corner, as shown.



- ▶ If you see Ver. 02.02, you already have the latest firmware and do not need to upgrade it.
- ▶ If you see Ver. 01.01 (or lower), you can upgrade it to Version 02.02.

To perform the upgrade, visit <http://support.epson.com> and click the Digital Photography icon.



Then follow the links to the P-2000 Drivers & Downloads page (click **Multimedia/Photo Storage Viewers > P-2000 > Drivers & Downloads**). Download the firmware update for your operating system (Windows® or Macintosh®), and follow the instructions provided with the download to perform the upgrade.

Note:

If you follow the link under News & Alerts (instead of clicking Drivers & Downloads), you can read a description of the enhancements supported by this upgrade.

Epson is a registered trademark of Seiko Epson Corporation.