

User Replaceable Items effective 12/01/2005

**PowerLite 62c / 82c / 76c**

<b><u>DESCRIPTION</u></b>	<b><u>PART NUMBER</u></b> <b><u>PL62c / 82c / 76c</u></b>
PL62c/82c AC Power Cable (2-prong cable) 3m length	210 6383
PL76c AC Power cable (2-prong cable) 1.8m length	210 6756
Computer VGA cable	207 1748
Lamp (V13H010L34)	H010L34
PL62c/82c Remote Control	128 0799
PL76c Remote Control	130 6200
Lens Cap Unit	130 4678
Soft (black) carrying case with adjustable shoulder strap	140 0702

Order user replaceable parts from an [Epson authorized parts distributor](#).

---- or ----

Locate an Epson Authorized Service Center to order user replaceable parts by using the "Help me find..." tool in the right column of the [Epson Support](#) home page.