

EPSON RC+ 6.1.1 Release Notes

January 29, 2010

Thank you for using EPSON RC+ 6.1.1. This document contains the latest information for this release. Please read before using this software.

DOCUMENTATION.....	2
GETTING STARTED	2
WHAT'S NEW IN VERSION 6.1.1	2
WHAT'S FIXED IN VERSION 6.1.1	2

Documentation

All RC+ manuals are in PDF format and are installed on the PC hard disk. These manuals are accessible from the EPSON RC+ 6.0 environment Help menu.

Getting Started

Read the Getting Started chapter in the EPSON RC+ 6.0 User's Guide. This chapter will refer you to the RC620 Controller manual Installation chapter. This contains information for initial connections and start up.

What's New in version 6.1.1

1. Added support for G1 series 3 axis robots.

What's Fixed in version 6.1.1

1. Fixed a problem where the Operator Window would not appear if Run | Test Auto Mode was executed while the I/O Monitor window was open.
2. Negative numbers can now be entered for conveyor upstream and downstream limits.
3. Fixed a problem for the Edit Project dialog. If point files were removed, they were not removed from the build tree display.