

PowerLite 1830 / 1915 / 1925W

<u>DESCRIPTION</u>	<u>PART NUMBER</u>
AC Power Cable (3-prong)	2080118
Lamp (V13H010L40)	1516823
Remote Control	1507996
Computer Cable	2110978
USB Cable	2121991
Air Filter Set	V13H134A08
Soft carrying case	1456324
PL1830 – Monitor CD	3104216

PL1915p / PL1925W

Wireless LAN Adapter 802.11 a/b/g Model: WN6501CEP (ELPAPO3)	2122537
Security Screw for Wireless I/F	130 2469
PL 1915 / PL1925: - EasyMP Network Projection V2.60 (Windows & Mac) - EasyMP Slide Converter Ver. 1.00 (Windows only) - EasyMP Monitor Ver.4.31 (Windows only)	3104215

Order user replaceable parts from an [Epson authorized parts distributor](http://www.epson.com/cgi-bin/Store/AboutEpsonConnection.jsp).
<http://www.epson.com/cgi-bin/Store/AboutEpsonConnection.jsp>

---- or ----

Locate an Epson Authorized Service Center to order user replaceable parts by using the “Help me find...” tool in the right column of the [Epson Support](http://www.epson.com/cgi-bin/Store/support/SupportIndex.jsp) home page.
<http://www.epson.com/cgi-bin/Store/support/SupportIndex.jsp>