

## User Replaceable Items effective 12/01/2005

### PowerLite 500c/ 700c / 710c

<b><u>DESCRIPTION</u></b>	<b><u>PART NUMBER</u></b>
AC Power Cable	201 7328
A/V Cable (RCA Plugs)	600 2366
Computer Cable (VGA Cable)	202 2604
Audio Cable	202 2956
PS/2 Mouse Cable	600 2771
Mac Mouse Cable	600 2772
USB Mouse Cable	600 2770
<b>Lamp - PowerLite 500c/700c</b> (ELPLP10B)	600 2703
Lamp Cover (B)	600 3234
Air Filter Frame (B)	600 3246
<b>Lamp- PowerLite 710c</b> (ELPLP10S)	600 2703
Lamp Cover (S)	600 2258
Air Filter Frame (S)	600 3103
Remote Control (PowerLite 500c/700c/710c)	600 2911
Lens Cap with String	600 2781
User's Manual (PowerLite 500c/700c/710c)	CPD-9732
Black, Soft Carrying Case (Portfolio style) (no shoulder strap)	754 4082

Order user replaceable parts from an [Epson authorized parts distributor](#).

---- or ----

Locate an Epson Authorized Service Center to order user replaceable parts by using the "Help me find..." tool in the right column of the [Epson Support](#) home page.