

User Replaceable Items effective 12/01/2005

PowerLite 5300 / 7200 / 7300

<u>DESCRIPTION</u>	<u>PART NUMBER</u>
AC Power Cable	201 7328
A/V Cable (RCA Plugs)	201 6048
Computer Cable (VGA Cable)	202 2604
Mac Adapter Set	202 3359
Audio Cable	202 2956
Main Cable	202 3367
PS/2 Mouse Cable	202 3368
Serial Mouse Cable	202 3369
Mac Mouse Cable	202 2370
Serial Cable	202 3642
Mac Serial Cable	202 3643
Lamp (ELPLP05)	103 8131
Remote Control	754 4009
Lens Cap with String	103 9683
User's Manual (PowerLite 5300)	754 1521
User's Manual (PowerLite 7200/7300)	754 1141
ELP Link III (PowerLite 5300/7200/7300)	754 4068

Order user replaceable parts from an [Epson authorized parts distributor](#).

---- or ----

Locate an Epson Authorized Service Center to order user replaceable parts by using the "Help me find..." tool in the right column of the [Epson Support](#) home page.