

User Replaceable Items effective 12/01/2005

PowerLite 5500c / 7500c / 5550c / 7550c

<u>DESCRIPTION</u>	<u>PART NUMBER</u>
AC Power Cable	201 7328
A/V Cable (RCA Plugs)5500/7500	201 6048
AV Cable (RCA Plugs)5550/7550	600 2366
Main Cable	202 3367
Computer Cable (VGA Cable)	202 2604
Mac Adapter Set	202 3359
Audio Cable (3.5mm Plugs)	202 2956
PS/2 Mouse Cable	202 2606
Serial Mouse Cable	202 3643
Mac Mouse Cable	202 2607
Lamp-PowerLite 5500/7500 (ELPLP06)	600 0073
Lamp-PowerLite 5550/7550 (ELPLP07)	600 1982
Remote Control(5500/5550/7500/7550)	754 4059
Lens Cap with String	103 8266
User's Manual ELP-5500c/7500c	754 1203
User's Manual ELP-5550c/7550c	754 1679
Soft Carrying Case	754 4060
Hand Strap	754 4062

Order user replaceable parts from an [Epson authorized parts distributor](#).

---- or ----

Locate an Epson Authorized Service Center to order user replaceable parts by using the "Help me find..." tool in the right column of the [Epson Support](#) home page.