

User Replaceable Items effective 12/01/2005

PowerLite 600p / 800p / 810p

<u>DESCRIPTION</u>	<u>PART NUMBER</u>
AC Power Cable	201 7328
A/ Cable (RCA Plugs)	600 2366
Computer Cable (VGA Cable)	600 3951
PS/2 Mouse Cable	600 2771
USB Mouse Cable	600 2770
Lens Cap with String	600 6185
Lamp (V13H010L15)	600 5727
Remote Control	600 6170
User's Manual (PowerLite 600p)	900 2056
User's Manual (PowerLite 800p/810p)	900 1682

Order user replaceable parts from an [Epson authorized parts distributor](#).

---- or ----

Locate an Epson Authorized Service Center to order user replaceable parts by using the “Help me find...” tool in the right column of the [Epson Support](#) home page.