

User Replaceable Items effective 12/01/2005

PowerLite 61p / 81p / 821p

| <u>DESCRIPTION</u> | <u>PART NUMBER</u> <u>PL61p / 81p / 821p</u> |
|--|---|
| AC Power Cable | 208 0118 |
| Computer VGA cable | 207 1748 |
| Lamp (V13H010L30) | H010L30 |
| USB Mouse Cable | 110 1569 |
| Audio Adapter Cable | 208 9445 |
| Remote Control (not available via the Epson Store). To purchase a replacement remote, contact the nearest Epson Service Center) | 128 0799 |
| Lens Cap Unit | 128 9316 |
| Soft Cushion Blue Carrying Case with shoulder strap | 128 7511 |

Order user replaceable parts from an [Epson authorized parts distributor](#).

---- or ----

Locate an Epson Authorized Service Center to order user replaceable parts by using the “Help me find...” tool in the right column of the [Epson Support](#) home page.