

User Replaceable Items effective 12/01/2005

**PowerLite 740c / 745c / 760c / 765c  
PowerLite 732c / 737c**

<b><u>DESCRIPTION</u></b>	<b><u>PART NUMBER</u></b>
AC Power Cord (2-prong)	207 1477
Computer VGA cable	207 1748
Lamp (V13H010L32)	H010L32
USB Mouse Cable	110 1569
Audio Adapter Cable	208 9445
Remote Control	129 1754
Lens Cap Unit	128 7422
Carrying Case with shoulder strap	128 7817
<u>PL745c only:</u> Wireless LAN Card	209 2601
<u>PL745c and PL737c only:</u> EasyMP CD-Rom, Ver. 3	302 2369
<u>PL737c only:</u> Wireless LAN card	2092679
<b>PL765c only: 802.11 g/b wireless PC card</b>	2105813
<b>PL765c only: EasyMP Ver.1.50 software CD for Windows and MAC includes:</b>	310050200
- <b>EMP NS Connection version 1.40 (Windows)</b>	
- <b>EMP NS Connection ver. 1.11 (MAC)</b>	
- <b>EMP Slidemaker 2 version 1.12</b>	
- <b>EMP Monitor version 3.04</b>	

Order user replaceable parts from an [Epson authorized parts distributor](#).

---- or ----

Locate an Epson Authorized Service Center to order user replaceable parts by using the "Help me find..." tool in the right column of the [Epson Support](#) home page.