

User Replaceable Items effective 12/01/2005

**PowerLite 750c / 755c**

<b><u>DESCRIPTION</u></b>	<b><u>PART NUMBER</u></b>
AC Power Cable (2-prong)	207 1477
Computer VGA cable	207 1748
Lamp (V13H010L32)	H010L32
Remote Control	129 1754
Lens Cap with lanyard	128 7422
Soft carrying case	128 7817
USB Cable	110 1569
Audio adapter cable (1/8" Stereo Jack to 2-RCA)	208 9445
PL755c: EasyMP version 1.50 software CD for Windows & Macintosh	3100502
PL755c: 802.11 g/b wireless PC card – Model: WN4301AEP	2105813

Order user replaceable parts from an [Epson authorized parts distributor](#).

---- or ----

Locate an Epson Authorized Service Center to order user replaceable parts by using the “Help me find...” tool in the right column of the [Epson Support](#) home page.