

**PowerLite 77c**

<b><u>DESCRIPTION</u></b>	<b><u>PART NUMBER</u></b>
Power Cable	146 7649
Lamp (V13H010L41)	146 3504
Remote Control	145 6639
Computer VGA cable	211 0978
CD for user's guide	CPD-23258R1
Soft (black) Carrying Case with shoulder strap	143 6644

Order user replaceable parts from an [Epson authorized parts distributor](#).

---- or ----

Locate an Epson Authorized Service Center to order user replaceable parts by using the "Help me find..." tool in the right column of the [Epson Support](#) home page.