

**PowerLite 7800p / 7800pNL / 7850p / 7850pNL /
7900pNL**

<u>DESCRIPTION</u>	<u>PART NUMBER</u>	<u>PART NUMBER</u> <u>7900pNL</u>
Power Cable	208 0118	208 0118
Audio Cable (RCA)	206 8506	n/a
Video Cable (RCA)	206 8507	n/a
Computer Cable (VGA Cable)D-Sub15,D -Sub15	207 1748	207 1748
Audio Cable	202 2956	n/a
USB Mouse Cable	110 1569	110 1569
Remote Control	125 0610	125 0610
Lamp (V13H010L22)	124 2848	H010L22
Lens Cap	124 3658	124 3658
Lens Cap Strings	600 2920 110 1629	110 1629
Strings Tack	600 2793 110 1580	110 1580
PL 7800p: EasyManagement Software CD Ver. 1.00	404 3563	302210500
User's Guide (PL7800p)	CPD-15988	CPD-18737
PL 7850p: User's Guide	CPD-16397	--
PL 7850p Wireless LAN Card	208 1852	n/a
PL 7850p: Easy MP CD-ROM	302 0894	n/a

Order user replaceable parts from an [Epson authorized parts distributor](#).

---- or ----

Locate an Epson Authorized Service Center to order user replaceable parts by using the "Help me find..." tool in the right column of the [Epson Support](#) home page.