

User Replaceable Items effective 12/01/2005

PowerLite 811p / 820p

<u>DESCRIPTION</u>	<u>PART NUMBER</u>
AC Power Cable	201 7328
A/ Cable (RCA Plugs)	206 8500
Computer Cable (VGA Cable)	206 8600
PS/2 Mouse Cable	206 8526
USB Mouse Cable	110 1569
Lens Cap with String	115 5329
Lamp (V13H010L15)	600 5727
Remote Control	600 6170
User's Manual	CPD-13953

Order user replaceable parts from an [Epson authorized parts distributor](#).

---- or ----

Locate an Epson Authorized Service Center to order user replaceable parts by using the "Help me find..." tool in the right column of the [Epson Support](#) home page.