

**PowerLite 83c / 822p / 83+ / 822+**  
**PowerLite 83V+**

<u>DESCRIPTION</u>	<u>PART NUMBER</u>
<b>Power Cable</b>	<b>1467676</b>
Lamp (V13H010L42)	2121325
Remote Control	<b>1456641</b>
Computer VGA cable	<b>2110978</b>
Soft carrying case	not included
Projector software CD	3101443
• EMP Monitor v4.10	
PL83c/PL822p CD includes User's Guide / product registration	CPPD-23328R1
PL83+ / 822+ CD includes User's Guide / registration	CPD-25113
Projector software CD (PL83+ / 822+)	310 766
• EMP Monitor v4.21	

Order user replaceable parts from an [Epson authorized parts distributor](http://www.epson.com/cgi-bin/Store/AboutEpsonConnection.jsp).  
<http://www.epson.com/cgi-bin/Store/AboutEpsonConnection.jsp>

---- or ----

Locate an Epson Authorized Service Center to order user replaceable parts  
by using the "Help me find..." tool in the right column of the

[Epson Support](http://www.epson.com/cgi-bin/Store/support/SupportIndex.jsp) home page.  
<http://www.epson.com/cgi-bin/Store/support/SupportIndex.jsp>