

User Replaceable Items effective 12/01/2005

PowerLite 8300i / 8300NL

<u>DESCRIPTION</u>	<u>PART NUMBER</u>
AC Power Cable	208 0118
Computer Cable(VGA Cable)	207 5028
Audio Cable (stereo mini jack)	202 2956
USB Mouse Cable	110 1569
Lamp (V13H010L23)	121 8653
Remote Control	123 1189 125 0610
Lens Cap Unit	121 8346
User's Guide Manual	CPD-16107
Projector Software CD (Ver. 1.00)	302 0524
Rear Cable Cover	123 5574
Air Filter Set (6 filters)	V13H134A02

Order user replaceable parts from an [Epson authorized parts distributor](#).

---- or ----

Locate an Epson Authorized Service Center to order user replaceable parts by using the “Help me find...” tool in the right column of the [Epson Support](#) home page.