

User Replaceable Items effective 12/01/2005

PowerLite 9300i / 9300NL

<u>DESCRIPTION</u>	<u>PART NUMBER</u>
AC Power Cable	208 0118
Computer Cable (VGA Cable)	202 2604
Audio Cable (stereo mini jack)	202 2956
Lamp (V13H010L26)	H010L26
Remote Control	123 1189
User's Guide Manual	CPD-17183
Projector Software CD (Ver. 1.01)	302 1154
Multi Screen Software CD	302 1331
Rear Cable Cover	123 5574

Order user replaceable parts from an [Epson authorized parts distributor](#).

---- or ----

Locate an Epson Authorized Service Center to order user replaceable parts by using the "Help me find..." tool in the right column of the [Epson Support](#) home page.