

User Replaceable Items effective 12/01/2005

PowerLite Home 10 / 10+

<u>DESCRIPTION</u>	<u>PART NUMBER</u>
AC Power Cable (2-prong cable)	207 1477
PL Home 10: Lamp ((V13H010L2H)	H010L2H
PL Home 10+: Lamp (V13H010L29)	H010L9H
Remote Control	126 6449
Lens Cap Unit	126 9621

Order user replaceable parts from an [Epson authorized parts distributor](#).

---- or ----

Locate an Epson Authorized Service Center to order user replaceable parts by using the “Help me find...” tool in the right column of the [Epson Support](#) home page.