

User Replaceable Items effective 12/01/2005

PowerLite Home 20

<u>DESCRIPTION</u>	<u>PART NUMBER</u>
AC Power Cable (2-prong cable)	207 1477
Lamp ((V13H010L33)	H010L33
Remote Control	140 3919
Lens Cap Unit	140 5035

Order user replaceable parts from an [Epson authorized parts distributor](#).

---- or ----

Locate an Epson Authorized Service Center to order user replaceable parts by using the “Help me find...” tool in the right column of the [Epson Support](#) home page.