

User Replaceable Items effective 8/27/2007

PowerLite S5

<u>DESCRIPTION</u>	<u>PART NUMBER</u>
AC Power Cable (2-prong cable)	146 7649
PL S5 Lamp (V13H010L41)	146 3504
Computer VGA Cable	211 0978
Projector Remote Control	145 6639
Soft (black) Carrying Case with shoulder strap	143 6644

Order user replaceable parts from an [Epson authorized parts distributor](#).

---- or ----

Locate an Epson Authorized Service Center to order user replaceable parts by using the "Help me find..." tool in the right column of the [Epson Support](#) home page.