

Bump and Print

About this Guide

This guide consists of 2 sections:

- **Overview** - A brief description of what bump and print is in a TrueOrder™ Kitchen Display System (KDS).
- **How to Configure** – Instructions for configuring bump and print.

Overview

An Epson TrueOrder KDS device can be configured to bump and print labels for individual items and/or entire orders on an Epson USB attached printer. This can be configured individually for any KDS devices in the system. Labels are typically printed on an Epson TM-L100 LFC printer.




Epson TM-L100 Printer

How to Configure


This guide assumes that you already have a Single or Multi-Station system setup as described in the TrueOrder KDS Quick Start Guides. This procedure can be followed to configure bump and print functionality in any TrueOrder KDS system.

1. Enable the bump and print functionality

1. Click **Stations**.
2. Select **Device Config**.
3. Select the **KDS device** you wish to configure (e.g. Kitchen).




4. Select **“Print Item on Bump”** and/or **“Print Ticket on Bump”**.
5. Click **Save**.




2. Custom Print Label Settings

1. Click **Application Settings**.
2. Select **Print Label**.
3. Select **Ticket Label** to configure **Print Ticket on Bump**.




- Required** fields configuration:
Configure the **Text Style** and **Paragraph** settings for **Order Number**, **Item Name** and **Quantity**. Refer to the **Print Label Preview** to confirm your settings.




- Personalize** configuration:
To add header text, input one line of header in **Header text line**, configure the style of this line and click **Add Line** to add this line. Follow similar procedures to add footer text.

To add QR code, input the text message in **Add message** under **QR Code** and select **QR Code Modal**.


Refer to the **Print Label Preview** to confirm your settings.



- Optional fields configuration:
For the optional fields: **Customer Name**, **Server Name**, **Modifiers (Special Instructions)**, **Labels (Information Lines)** and **Date/Time**, select the checkbox to enable the fields and configure the style of each field. Adjust based on the live preview of **Print Label Preview** window.



- Select **Item Label** and follow the same procedure to configure **Print Item on Bump**.
- Click **Save**.



- Click  to publish settings.