

README\_ENGLISH.TXT

EPSON RC+ 5.0

Version 5.4.7

Copyright (c)

1994-2016

SEIKO EPSON  
CORPORATION, INC.

Installation Notes

=====

1. EPSON RC+ 5.4.7 can be  
installed on the following  
operating systems:

Windows 10 Professional  
32 Bit or 64 Bit

Windows 8 Professional  
32 Bit or 64 Bit

Windows 7 Professional  
32 Bit or 64 Bit

Windows Vista Business  
with Service Pack 2 or greater

Windows XP Professional  
with Service Pack 3 or greater

2. You must be logged in as  
Administrator to install.

3. To install:

a. Insert the EPSON RC+  
5.0 installation DVD.

b. The setup program will

start automatically.

c. If setup doesn't start, run `d:\EpsonRC50\setup.exe` where `d:` is the DVD drive.

d. Follow the instructions on the screen.

4. During installation, Microsoft .NET Framework 3.5 will be installed if not found.

5. During installation, Adobe Reader will be installed if not found.

6. When you reboot the system for the first time after installation, you must use

the same login name that  
you used for installation.  
This is so that system  
files are updated  
properly.

7. In order run SPEL  
programs, you must connect  
your PC  
to an RC170/RC180  
controller.

## Getting Started

=====

After installation, there will  
be a program group called  
"EPSON RC+ 5.0". Two desktop  
shortcuts are created:  
one for normal mode, and one  
for simple mode.

To start EPSON RC+ 5.0, either double click on one of the desktop shortcuts or click Start, then select EPSON RC+ 5.0 or EPSON RC+ 5.0 Simple from the EPSON RC+ program group.

The very first time you run EPSON RC+, no projects will be open. You must create a new project by selecting New Project from the Project menu. By default, the next time you run EPSON RC+, the last project you were working on will be opened automatically.

## Getting Help

=====

EPSON RC+ has context sensitive help. Press the F1 key at any time to get help for the current operation, or click on the ? button for the current dialog box.

You can get help for SPEL+ language keywords in the Edit window by placing the insertion point anywhere within a keyword and pressing the F1 key.

You can also select Contents from the Help menu to open the Help table of contents. First time users should review the Introduction in the help contents.