


Epson Stylus® NX420 Series Start Here


Read these instructions before using your product.

1 Unpack




Caution: Do not open ink cartridge packages until you are ready to install the ink. Cartridges are vacuum packed to maintain reliability.

Remove all protective materials.




2 Turn on

- 1 Connect the power cable.




Caution: Do not connect to your computer yet.


- 2 Press the  On button.



3 Select language

- 1 To select **English** as your language, press  **Start**.




Note: If you want to change the language, press ◀ or ▶ to select it, then press  **Start**.


4 Install ink cartridges

Note: Do not load paper yet.


- 1 Lift up the scanner, then open the cartridge cover.



- 2 Shake the ink cartridges gently 4 or 5 times, then unpack them.



- 3 Remove only the yellow tape from each cartridge.




Caution: Don't remove any other seals or the cartridges may leak.




411841500

EPSON®
EXCEED YOUR VISION


- 4 Insert the cartridges in the holder for each color.




- 5 Press each cartridge down until it clicks.



- 6 Close the cartridge cover. Press down until it clicks.



- 7 Lower the scanner.

- 8 Press the  **Start** button to charge the ink.


Priming takes about 2 minutes.

Note: Your printer ships with full cartridges and part of the ink from the first cartridges is used for priming the printer.


Caution: Don't turn off the printer while it is priming or you'll waste ink.

5 Load paper


- 1 Open the paper support and pull up the extensions.




- 2 Open the output tray, pull out the extensions, and raise the stopper.




- 3 Squeeze the edge guide as you slide it all the way to the left.



- 4 Load letter or A4-size paper against the right edge and behind the tab, with the printable side face up.



- 5 Slide the edge guide over.



Continue with section 6 to choose your connection type.

6 Choose your connection

You can connect your printer to your existing network wirelessly or directly to your computer using a USB cable (not included). See below for details on each connection method.

Wireless Connection

You will need to install the software on every computer that will print to the printer. Temporary use of a USB cable (not included) is recommended for the first installation only. After the printer is connected to the network, you will be prompted to remove the USB cable.

If you're using Mac OS® X 10.6 or don't have a USB cable, you can use the buttons on the printer to select wireless settings instead.

Make sure you know your network name (SSID) and network password:

- Network name _____
- Network password _____


If you don't have this information, contact the person who set up your network.

Direct USB Connection


Make sure you have a USB cable (not included). Do not connect the printer to your computer until you're instructed to do so.

7 Install software


- 1 Make sure the printer is **NOT CONNECTED** to your computer.



Windows®: If you see a Found New Hardware screen, click **Cancel** and disconnect the USB cable. You can't install your software that way.




- 2 Insert the NX420 Series software CD.




Windows: If you see the AutoPlay window, click **Run Setup.exe**. If you see the User Account Control screen, click **Yes** or **Continue**.

Macintosh®: Double-click the  **Epson** icon, if necessary.

- 3 Click **Install** and follow the on-screen instructions.



Control panel overview




Any problems?

If you experience problems during setup, see below:

Network setup was unsuccessful.



- Make sure you select the right network name.
- If your network has security enabled, make sure you enter your network password (WEP key or WPA passphrase) correctly. If it has uppercase (**ABC**) or lowercase (**abc**) letters, make sure you enter them correctly.



Press to select upper-case letters (ABC), lower-case letters (abc), or numbers and symbols (123).

Press + or - to enter characters.

Press to move to the next character.

Press to delete.

Press the **Start** button when you're finished entering your password.


- If you see a firewall alert message, click **Unblock** or **Allow** to let setup continue.

You see error messages on the printer's LCD display screen.

See your *Quick Guide* for troubleshooting information.

Setup is unable to find my printer after connecting it with a USB cable.

Make sure it is securely connected as shown:



Any questions?

Quick Guide

Basic instructions for wireless setup, printing, copying, and scanning.



User's Guide

Click the desktop shortcut to access the online *User's Guide*, how-to videos, software downloads, Epson Supplies CentralSM, and more (requires an internet connection).



On-screen help with your software

Select **Help** or **?** when you're using your software.

Epson Technical Support

Visit epson.com/support where you can download drivers, view manuals, get FAQs, or e-mail Epson.

You may also speak with a support specialist by calling (562) 276-4382 (U.S.) or (905) 709-3839 (Canada), 6 AM to 6 PM, Pacific Time, Monday through Friday. Days and hours of support are subject to change without notice. Toll or long distance charges may apply.

Need paper and ink?

Try Epson paper with DURABrite[®] Ultra Ink for professional results. For the right supplies at the right time, you can purchase them at Epson Supplies Central at www.epson.com/ink3 (U.S. sales) or www.epson.ca (Canadian sales). You can also purchase supplies from an Epson authorized reseller. To find the nearest one, call 800-GO-EPSON (800-463-7766).

DESIGNED *for* EXCELLENCE[™]
Epson printers, ink and specialty papers.

Genuine Epson Paper

Epson offers a wide variety of papers to meet your needs; visit Epson Supplies Central for more information.



Premium Presentation Paper Matte

Heavy weight, non-glare card stock for school and business projects plus photos.

Genuine Epson Inks



Look for the numbers below to find your cartridges. It's as easy as remembering your number!



NX420 Series Ink Cartridges

Color	Moderate-capacity (For lighter use)	Standard-capacity
Black	124	125
Cyan	124	125
Magenta	124	125
Yellow	124	125

Epson and Epson Stylus are registered trademarks, Epson Exceed Your Vision is a registered logomark, and Supplies Central is a service mark of Seiko Epson Corporation. Designed for Excellence is a trademark and DURABrite is a registered trademark of Epson America, Inc.

General Notice: Other product names used herein are for identification purposes only and may be trademarks of their respective owners. Epson disclaims any and all rights in those marks.

This information is subject to change without notice.