

SureColor[®] F3070 Required Maintenance



Scan QR code to watch maintenance videos

There is no time for downtime when running your business.

Clean machines run better. When enough debris gets into the various components, wear can be accelerated, and output is negatively impacted. As the debris builds over time, it can impede the machine's performance and reduce reliability.

It is the customer's responsibility to conduct maintenance on time, as outlined below, to keep their printer up and running.

Maintenance Frequency	Customer Steps
Daily	 Agitate White Ink Cartridges¹ Nozzle Check¹ Printhead Cleaning Cycles
Weekly	 Suction Cap Cleaning Clean Around in Printhead
Monthly	 Agitate Color Ink Cartridges¹ Check for New Firmware/Software¹ Check Flushing Pads and Air Filters¹
As Needed	 Replace Head Cleaning Set¹ Replace Anti-Dry Cap Tops¹ Replace Air Filters¹

User Maintenance Schedule and Steps

Please refer to product's Operator Maintenance, User's Guide, User Self Service Guide for detailed maintenance requirements.

User maintenance is required. User maintenance is not included as part of the Extended Service Plans. Create a maintenance schedule, update maintenance records, and designate a regular maintenance employee to ensure your printer's productivity.

Customer Responsibilities

Customer is responsible for sourcing maintenance equipment, which includes the following approved parts:

• Cleaning cloth (Product code: C13S210050)

¹ Maintenance videos do not cover these steps. Please refer to product's Operator Maintenance, User's Guide, and User Self Service Guide for more information.

EPSON, SureColor are registered trademarks and the EPSON logo is a registered logomark of Seiko Epson Corporation. All product and brand names are trademarks and/or registered trademarks of their respective companies. Epson disclaims any and all rights in these marks. Copyright 2023 Epson America, Inc.